

Gehmann 404R Jacket Sizing Guide

Note: When measuring, please wear the clothing you would normally wear under your shooting jacket and pants when shooting

The measurements in the chart are the measurements of the jacket – not of the body!

Example: If your chest measurement is 100cm and in the chart there is a chest measurement of 100cm for size 52 you have to choose a minimum one size larger to ensure the jacket fits

Please use the measurement diagram guide below when taking your measurements

Measurements are in cm's

Womens Standard Sizes

Diagram No	1	2	3	4	5	6	7	A	9	10
Size	Shoulder to Shoulder	Shoulder to Neck	Chest	Waist	Hips	Biceps	Outside Wrist	Length at Back	Outside Sleeve Length	Shoulder to Elbow
36	37	9	90	82	90	37	24	67	57	31
38	38	9.5	94	86	94	38	24.5	68	58	31.5
40	39	10	98	90	98	39	25	69	59	32
42	40	10.5	102	94	102	40	25.5	70	60	32.5
44	41	11	106	98	106	41	26	71	61	33
46	42	11.5	110	102	110	42	26.5	72	62	33.5
48	43	12	114	106	114	43	27	73	63	34
50	44	12.5	118	110	118	44	27.5	74	64	34.5

