

# Gehmann 418 Jacket Sizing Guide

**Note: When measuring, please wear the clothing you would normally wear under your shooting jacket and pants when shooting**

**The measurements in the chart are the measurements of the jacket – not of the body!**

**Example: If your chest measurement is 100cm and in the chart there is a chest measurement of 100cm for size 52 you have to choose a minimum one size larger to ensure the jacket fits**

**Please use the measurement diagram guide below when taking your measurements**

**Measurements are in cm's**

## Mens Standard Sizes

Diagram No	1	2	3	4	5	6	7	A	9	10
Size	Shoulder to Shoulder	Shoulder to Neck	Chest	Waist	Hips	Biceps	Outside Wrist	Length at Back	Outside Sleeve Length	Shoulder to Elbow
44	41	9.5	92	84	92	38	30.5	71	60	32
46	42	10	96	88	96	39	31	72	61	32.5
48	43	10.5	100	92	100	40	31.5	73	62	33
50	44	11	104	96	104	41	32	74	63	33.5
52	45	11.5	108	100	108	42	32.5	75	64	34
54	46	12	112	104	112	43	33	76	65	34.5
56	47	12.5	116	108	116	44	33.5	77	66	35
58	48	13	120	112	120	45	34	78	67	35.5
60	49	13.5	124	116	124	46	34.5	79	68	36
62	50	14	128	120	128	47	35	80	69	36.5
25	47	10	114	106	110	44	34.5	69	60	31
26	48	10.5	118	110	114	45	35	70	61	31.5
27	49	11	122	114	118	46	35.5	71	62	32
28	50	11.5	126	118	122	47	36	72	63	32.5
29	51	12	130	122	126	48	36.5	73	64	33
30	52	12.5	134	126	130	49	37	74	65	33.5

# Womens Standard Sizes

Diagram No	1	2	3	4	5	6	7	A	9	10
Size	Shoulder to Shoulder	Shoulder to Neck	Chest	Waist	Hips	Biceps	Outside Wrist	Length at Back	Outside Sleeve Length	Shoulder to Elbow
36	37	9	90	82	90	37	24	67	59	31
38	38	9.5	94	86	94	38	24.5	68	60	31.5
40	39	10	98	90	98	39	25	69	61	32
42	40	10.5	102	94	102	40	25.5	70	62	32.5
44	41	11	106	98	106	41	26	71	63	33
46	42	11.5	110	102	110	42	26.5	72	64	33.5
48	43	12	114	106	114	43	27	73	65	34

