

WATER RESISTANCE GUIDE :

CASE WATER RESISTANCE LEVELS*

REFER TO THE CHART BELOW TO HELP YOU CHOOSE A WATCH SUITABLE FOR YOUR WATER-BASED ACTIVITIES.



SPINNAKER

NOTE THAT THE BELOW SERVES ONLY AS A GUIDE. ACTUAL WATER RESISTANCE MAY VARY DEPENDING ON A NUMBER OF FACTORS INCLUDING WATER TEMPERATURE, WATER SALINITY, AND USE UNDER WATER.

THE WATER RESISTANCE OF YOUR TIMEPIECE MAY BE EVENTUALLY BE COMPROMISED OVER TIME WITH GENERAL WEAR AND TEAR AND USE OF YOUR TIMEPIECE UNDER ADVERSE CONDITIONS.

ALWAYS REMEMBER TO EMPLOY THE SCREW DOWN CROWN IF AVAILABLE TO AFFECT THE WATER RESISTANCY OF YOUR TIMEPIECE. WARRANTY MAY NOT BE ENTERTAINED IF THE SCREW DOWN CROWN HAS NOT BEEN PROPERLY EMPLOYED.

NOTE THAT YOU SHOULD NEVER WEAR YOUR WATCH IN A JACUZZI, OR STEAM ROOM WHERE STEAM MAY ENTER INSIDE THE CASE DESPITE THE WATER TIGHT SEALS USED TO PROTECT YOUR WATCH. THIS MAY CAUSE CONDENSATION INSIDE YOUR WATCH WHICH MAY EFFECT AND DAMAGE THE INNER WORKINGS OF YOUR WATCH.

*SPINNAKER WATCHES, ITS MANUFACTURER , BRAND OWNER OR ANY OF ITS AFFILIATED COMPANIES ACCEPT NO LIABILITY FOR DEATH OR INJURY RESULTING FROM USE, MISUSE OR FAILURE ON THE PART OF THIS WATCH

WATER RESISTANCE CHART	30M / 3ATM	50M / 5ATM	100M / 10ATM	150M / 15ATM	200M / 20ATM	300M / 30ATM	500M / 50ATM	1000M / 100ATM
SPLASH/ SHOWERING	✓	✓	✓	✓	✓	✓	✓	✓
SWIMMING/ BATHING	✗	✓	✓	✓	✓	✓	✓	✓
SWIMMING/SNORKELING/ WATER SPORTS	✗	✗	✓	✓	✓	✓	✓	✓
FREE DIVING	✗	✗	✗	✓	✓	✓	✓	✓
SCUBA DIVING	✗	✗	✗	✗	✗	✓	✓	✓
PROFESSIONAL DEEP SEA DIVING	✗	✗	✗	✗	✗	✗	✓	✓