

2015-2019 Ford FSP5 SOTF

Instructions


1. After mounting your switch on the dash, you will run the harness through the fire wall. Into the engine bay.



2. Locate the harness in the engine bay and pull it through with out causing tension. You will now put the YELLOW and White wire in to the connector like so;



3. Locate your factory Fuel Temperature Sensor and unplug it.



4. You will now plug the temp sensor harness in to the SOTF



Connector;

5. Zip-tie everything in place and clean up install before taking it out for a test drive

*Tuning sold separately.