

babybee

Stroller Manual



babybeeprams.com.au

IMPORTANT! Keep For Future Reference
Australian Safety Standard: AS/NZS 20088:2013



Welcome aboard and
thanks for choosing
Babybee.



Read me first

Before we start, there's a few important things you need to be aware of:

Safety first

The safety of your family is our number one priority. Please take the time to carefully read this manual and all warning notices on page 19-21 before getting started. Incorrect assembly or use can result in serious injury or even death.

▲ WARNING

To prevent injury from choking, carefully remove and immediately move out of reach all plastic packaging. Never leave your child unattended with the pram or packaging.

▲ WARNING

Your canopy acts as a head barrier and important safety feature. Only use the stroller with the canopy fully attached.

Return Policy

If you decide that the **ROVER** is not the perfect one for you, we offer a Free Return Policy when returned in original condition and packaging (with no signs of usage). Please be mindful of this when unboxing and setting up. Refer to our website for full terms and conditions.

Support

If at any stage you require assistance with set up or use, please refer to our 'After Sales Support' page on our website. There, you'll find instructional videos and FAQ's. Or feel free to email us anytime at:

hello@babybeeprams.com.au

Enjoy the ride, from all of us at

 **babybee**

What's in the box

Please check that you have all the correct parts before getting started.



- 1** - Frame & basket
- 2** - Seat & harness covers
- 3** - 2x Rear wheels
- 4** - Belly bar
- 5** - 2x Front swivel wheels
- 6** - Brake bar
- 7** - Canopy
- 8** - Seat liner
- 9** - Handlebar bag
- 10** - Rain cover (compatible with seat & bassinet)
- 11** - UV/Mosquito/Sleep Cover
- 12** - User manual

Contents

- 04 What's in the box checklist
- 06 Step 1: *Setting up your frame*
- 08 Step 2: *Setting up your seat & canopy*
- 10 Using your ROVER
- 10 Rear brake
- 10 Front swivel wheels
- 11 Seat recline
- 11 Adjusting the footrest
- 12 Safety harness
- 13 Canopy
- 13 Adjusting the handlebar
- 14 Folding the Stroller
- 15 Free accessories
- 16 Tips for maintaining your pram
- 17 Cleaning
- 18 Warranty
- 19 Safety warnings

Step 1 - Setting up your frame

- 1** To release the frame from the folded position, press the black button on the right frame release lever, and pull both release levers back towards the handle.



- 2** To open, lift up and swing the lower section into place ensuring you hear it "click" into place.



- 3** Attach the brake bar to the rear of the frame. Push until you see the silver locking pins click into place.



4

To attach the rear wheels push each wheel pin into the sides of the brake bar until you hear a "click". Give them a tug to ensure they are attached securely.

click!



5

Next, insert each front wheel pin into the centre of the socket ensuring you hear them "click" in. Give each wheel a firm tug to ensure they are secure.

Your frame should now be set up.

click!



Step 2 -

Setting up your seat & canopy

⚠ WARNING

- Your canopy acts as a head barrier and important safety feature. Only use the stroller with the canopy fully attached.

1

Line up the seat connectors with the frame and press downwards. Listen for the 'click' and ensure it is securely locked in place.



2

To recline the seat, lift the seat recline latch located at the canopy end of the frame and tilt the seat forward or back.

Note: The seat can be faced in the forward or rear facing position.



Refer to page 12 for instructions on adjusting your harness.

⚠ WARNING

- This stroller seats one passenger with a maximum weight limit of 20kg.
- Not suitable for a child under 6 months old who cannot sit up unaided.
- Do not allow your child to climb unassisted into the stroller.
- Maximum weight for the seat pocket is 1kg.

TIP: Your **canopy** visor may need a little TLC after shipping. To get it looking nice and new again simply apply heat from a clothes steamer or hair dryer to remove any wrinkles (just be careful to scorch the fabric). This is not covered under warranty.

- 3** To attach the canopy, first secure it to the frame with the zip starting from the left side (when facing the seat).



- 4** Next attach the plastic canopy connectors onto the sides of the frame (**TIP:** attach from top to bottom). You'll notice a round guide on each side, the connectors should attach over these guides.



- 5** Finally, insert the belly bar into the belly bar sockets on the seat frame. Always give the bar a firm tug to ensure its secure.

Note: To remove from one side or both, press the button on the side you want to release, and pull the belly bar out.



⚠ WARNING

- Please ensure that your child correctly wears the fitted and adjusted safety harness at all times with all 5 straps secured.
- Never leave the harness buckled when not fitted to the child in the stroller. The harness can form loops which may cause a strangulation hazard.

Using your ROVER

Correct use:

Any vehicle with moving parts needs to be used and treated with care and given regular maintenance to remain safe and in good condition. Please be gentle, don't overload it, avoid excessive off-road use and be sure to follow the maintenance instructions on page 16 to keep your **ROVER** looking and feeling newer for longer!

Rear brake:

When stopping, use the brake at all times by pressing down on the bottom of the red brake paddle with your foot until you feel it click into place. To start travelling again press down on the top of the red lever with your foot to disengage the brake and off you go!



Front swivel wheels:

When travelling fast along straight surfaces or across uneven terrain, the front wheels may spin or cause what's commonly known as "wheel shudder".

To lock the front swivel wheels into place, press down on the wheel lock buttons (located on the top of the wheel sockets). To go back to 360° swivel mode, press the buttons again.

To remove the front wheels, press the button on the side of the wheel socket and pull the wheel down.



Rear wheels:

To remove the rear wheels, press the button located on the brake bar and pull the wheel off.



Basket:

The **ROVER** basket has been tested to hold 8kg. Overloading the basket with more weight may cause the basket to break.

Reclining the seat:

The seat can recline to 4 set positions. Fully lift the seat recline latch (located at the top of the canopy) and recline the seat to the desired position.



Adjusting the footrest:

Press both footrest buttons simultaneously and adjust the footrest to the desired position.



Using your ROVER

Safety Harness:

Always engage the brake before placing your child in the stroller.

To secure the harness:

- 1 Attach each of the 4 harness straps into the central buckle.
- 2 Adjust the length of each strap to ensure it fits nice and snug.
- 3 Always give the harness a tug to ensure it's secure.
- 4 To release press the button in the middle of the buckle.



⚠ WARNING

Always use the harness when your child is in the stroller. Always adjust the harness appropriately for your child's size.

To adjust the height of the harness straps:

- 1 Depending on your child's height, thread the shoulder strap through the appropriate slot on the seat.
- 2 Ensure it is thread through the corresponding slot of the seat liner.
- 3 Adjust the strap length using the buckle as required.



Having trouble?

Visit our website for a video tutorial on how to adjust the harness.

Canopy:

Adjust the canopy as needed to protect your child from the sun and wind. For maximum protection, use the zip to extend the canopy to its maximum length.



⚠ WARNING

- Your canopy acts as a head barrier and important safety feature. Only use the stroller with the canopy fully attached.

Adjusting The Handlebar:


Push the button in the middle of the handlebar and pull or push to your desired height.



Folding the Stroller

Recommended as the safest option:

- 1 Before folding, ensure that the front wheels are unlocked.
- 2 Remove the stroller seat by lifting the release levers on either side.
- 3 Push the black button on the frame release lever and then pull both black release levers up the frame.
- 4 Push down on the handlebar to close it.
- 5 Then you can lift the frame up using the carry bar and the front wheels will close inwards.
- 6 The frame has an automatic lock that ensures that it stays closed while you are carrying or storing the pram. To ensure that it has engaged, always push the front section of the frame closed as far as you can and give it a pull to ensure you cannot release it.



⚠ WARNING

- Always take care when folding the frame and lift the frame from the carry bar.
- Always remove the car capsule, bassinet or seat prior to folding and carry the frame and seat/bassinet separately. This is the safest carry method for your back.

Free Accessories

Rain Cover (compatible with seat & bassinet)

Pull the rain cover and elastic over the top of the canopy and then over the end of the bassinet. The elastic will prevent the rain cover from flying away in the wind. Please ensure the air vents are located on either side so that air can pass through.

Note: The cover will be looser on the bassinet due to its shorter frame and canopy.



UV / Mosquito / Sleep Cover

Fully extend the canopy. Attach the press studs onto the sides of the canopy connectors, then hook the cover over the base of the seat and top of the canopy.

Note: Compatible with seat only, covering your bassinet with any fabric could result in overheating or reduced oxygen.



Handlebar bag

Secure the straps with the press studs over the handlebar. Be careful carrying liquids in the handlebar bag. Hot liquids may burn you or your child.



Seat Liner

Attach the seat liner by threading the harness straps from the seat through the corresponding slot.



⚠ WARNING

- Do not carry bags from the handlebar other than the one provided by Babybee.
- Do not use parts or accessories that are not approved for use with the Babybee ROVER range. Doing so may be unsafe and may also void your warranty. (e.g. toddler boards, bag hooks, rain covers, etc).
- Never leave covers on or over the pram indoors, in very hot weather or near a heat source. Always supervise and monitor your child regularly whilst the pram is covered.

Tips for maintaining your pram.

Excessive wear can reduce the effectiveness and safety of your pram. To keep your ROVER in good working condition and ensure that it lasts as long as possible will require regular maintenance and you will need to service your pram every 6 months.

Regular maintenance should include:

Inspecting the locking devices, levers, joints, buttons, brakes, wheels, safety harness and fixtures to ensure they are secure, moving freely and in fully working order.

If any parts of the pram have become stiff, difficult to operate or begin to squeak, first ensure that dirt is not the cause. Then try a light application of a sprayable silicone lubricant, ensuring that it penetrates between the components. (Note: Only use lubricant labeled 'Silicone Lubricant', other lubricants can deteriorate the plastic parts of your pram and also attract dirt and dust e.g. DO NOT use standard WD40). We recommend WD-40 SPECIALIST Silicon Lubricant or SCA Silicone Spray available from Supercheap Auto, Bunnings and most hardware stores.

Preventing rust & mould

After exposure to wet or damp conditions (especially trips to the beach, snow or in the rain), leave the pram fully open in a warm, well ventilated environment to prevent rust and mould. You may need to dry with a soft, lint free cloth. Left damp it will encourage mildew, mould or rust to form, damaging the pram.

Correct Use

The **ROVER** has been designed for urban living and weekend adventures which means it's ideal for walking on sealed footpaths, in shopping centres, cafes and down at your local park. Use of the **ROVER** off-road or over uneven terrain will clearly place more stress on the frame and wheels and cause it to wear out faster. For this reason we recommend "weekend adventures" and not regular off-road use.

⚠ WARNING POISONOUS, TOXIC SUBSTANCE. USE WITH CARE.

Ensure children are not present when applying silicon lubricant or allowing it to dry. Always spray outside or in a well ventilated area. Ensure you use minimal product and wipe away excess solution before use.

Storage

- Do not leave the pram in direct sunlight for prolonged periods of time to avoid colour fade.
- Do not leave in your car on days of extreme heat or near any heat source or fire.
- Do not store the stroller with heavy items on top of it.
- Store the pram in a dry, well-ventilated and safe place.

Spare Parts

- The brakes and wheels are subject to normal wear and should be replaced if necessary.
- Spare parts are available for purchase on the Spare Parts page of our website: **babybeeprams.com.au**
If the part you require is not listed please email us for a quote.

Cleaning Instructions

For a comprehensive deep cleaning guide (we recommended you do this every 6 months) please refer to our website.

- Use a soft brush to brush down the pram and remove any dirt or dust making sure you get into all the nooks and crannies (i.e inside the wheel hubs, inside the joints from all folding parts etc). You could also give it a good vacuum.
- At the first sign of rust, remove with steel wool.
- All plastic, fabric and metal parts of the pram may be sponged clean with a soft cloth in warm water and a mild detergent.

- Wipe dry with a soft towel or cloth and allow all parts to dry thoroughly before using.
- The seat liner and bassinet mattress liner are machine washable on a delicate setting (maximum water temperature of 30°C) however handwashing will keep them looking newer for longer.

Do not

- Do not immerse the seat or canopy in water, sponge clean only.
- Do not clean with abrasive materials or using ammonia, bleach, solvents, caustic or spirit-based cleaners.
- Do not press or iron.
- Do not rub or wring fabric.
- Do not tumble dry.
- Do not dry clean.

⚠ WARNING

- Do not clean your pram with children around.
- Do not dismantle or alter any part of the folding mechanisms, frame, brake axle or wheels for cleaning or any other reason.
- Do not use if any part is broken, torn or missing. Replacement parts are available from our website or by contacting us.

Failing to adhere to these maintenance and cleaning instructions could damage or effect the safety of your pram and may void your warranty.

Warranty Information

Your ROVER comes with a 2 year defects warranty to cover against faults in materials and workmanship when your pram is used under normal conditions, according to our user manuals and technical specifications.

The benefits under our warranty are in addition to other rights and remedies under the law in relation to consumer goods: Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

The warranty period starts from the date that your pram is dispatched from our warehouse and is valid in Australia only.

To make a claim email us at: **hello@babybeeprams.com.au** with a detailed description, video and/or photos of the defect and a photo of the batch number, which is located inside the back of your basket. Our warranty team will then determine the best way to resolve any defects or faults. Babybee reserves the right to repair, exchange or replace the damaged item with a replacement part. Some parts may be replaced with newer model parts as the pram is improved over time.

The warranty is not valid in the following cases:

- Defects or faults resulting from improper assembly, care or use as outlined in our user manual;
- Defects or faults resulting from an accident, airline or transport damage;
- Normal wear and tear, including scratches to the frame or colour fading of the fabrics;
- Damage to handle/bellybar grips or fabrics (i.e. scuffs or tears) as a result of normal handling and daily use;
- Corrosion, mould or rust due to extreme environmental conditions, including high humidity, salt spray, snow or due to lack of regular maintenance.
- Products that are purchased second hand or from an unauthorised distributor;
- Using a part or accessory that is not compatible with the product and/or not manufactured by Babybee Prams;
- If you or a third party has attempted to modify or repair the pram without having received written permission from Babybee Prams.
- Claims from anyone other than the original purchaser (i.e. no longer valid if gifted or sold to another individual)
- Damage resulting from extreme heat conditions (i.e leaving in car on hot days)
- Customer dissatisfaction with the product in terms of fit, weight, functionality, colour or design.

Safety Warnings

The babybee ROVER is designed and tested to comply with AS/NZS2088:2013.

The ACCC has identified several key hazards associated with prams and strollers which could result in serious injury or even death:

- The pram or stroller rolling away from the carers control
- Limb and finger injuries
- Falls
- Strangulation or suffocation

Please read and follow the below warning notices before using your stroller:

⚠ WARNING

To avoid injury or death:

- Always apply the brakes whenever the pram/stroller is stationary.
- Do not leave children unattended.
- Secure the child in the stroller harness at all times.
- Do not carry extra children or bags on the pram/stroller.
- Make sure children are clear of any moving parts if you adjust the pram/stroller.
- Your canopy acts as a head barrier and important safety feature. Only use the stroller with the canopy attached.

Seat Specific

- This stroller seats one passenger with a maximum weight limit of 20kg.
- Not suitable for a child under 6 months old who cannot sit up unaided.
- Do not allow your child to climb unassisted into the stroller.

Safety Harness

- Please ensure that your child correctly wears the fitted and adjusted safety harness at all times with all 5 straps secured.
- Never leave the harness buckled when not fitted to the child in the stroller. The harness can form loops which may cause a strangulation hazard.

Bassinet Specific

- Maximum weight that can be carried in the bassinet is 9kg.
- Do not use the bassinet once the child can sit up unaided.
- Not to be used for overnight or unsupervised sleeping.
- Only use the bassinet in a flat position. Do not recline.
- Do not add additional mattress or padding inside the bassinet.
- To reduce the risk of SIDS, paediatricians recommend healthy infants be placed on their backs to sleep, unless otherwise advised by your physician.

Safety Warnings Continued

Accessories & replacement parts

- Do not use parts or accessories that are not approved for use with the Babybee ROVER range. Doing so may be unsafe and may also void your warranty. (e.g. toddler boards, bag hooks, rain covers etc)

Carrying your stroller

- To avoid finger entrapment, keep your own and your children's fingers clear of any folding parts.
- Do not lift or carry the stroller when occupied by your child.
- Do not lift or carry the stroller when fully assembled. Only lift and carry after folding.
- Always remove the car capsule, bassinet or seat prior to folding and carry the frame and seat/ bassinet separately.
- Ensure that the automatic frame lock is engaged before lifting or carrying the stroller.
- Make sure the stroller and all parts are secured when being transported in a vehicle.

General safety

- This is not a toy. Do not allow your child to climb, stand on or play with the stroller.
- Do not use the pram in a manner for which it is not designed.
- Keep children clear of the pram before making any adjustments.
- Not suitable for running, rollerblading or skating.
- Remove your child and fold the stroller/pram when going up or down stairs or escalators.
- Take your child out of the stroller when travelling by bus, tram or train.
- Gentle sloping surfaces may be unstable. On steeper sloping and uneven surfaces, there is a possibility that the pram may tip over and you may need to remove your child.
- Do not use if any part is broken, torn or missing. Replacement parts are available from our website or by contacting us.
- Do not use or leave the pram near open fire or exposed flame.
- Never leave rain covers, canopy/ bassinet covers on or over the pram indoors, in a hot atmosphere or near a heat source. Always supervise whilst the pram is covered.

- Always ensure that the frame and the seat/bassinet/car capsule are correctly engaged before using the product.
- Do not overload the pram with additional children, bags, other items or accessories.
- Bags and other items must not be hung from the handle bar as they may damage the frame or otherwise cause the pram to become unbalanced and tip over.
- Do not allow children to stand on the axle/brake bar between the wheels. This is unsafe and could damage the stroller.

Maximum weight limits:

- Maximum weight for a child in the bassinet is 9kg.
- Maximum weight for a child in the seat is 20kg.
- Maximum weight for items in the basket is 8kg.
- Maximum weight for the seat pocket is 1kg.
- Maximum weight for the handlebar bag is 1kg.

Supervision

- Never leave your child unattended with the stroller. It should only be used under adult supervision.

Others using your pram

- If the stroller is being used by someone unfamiliar with it (such as grandparents) always explain to them how the stroller works and its safety features.

Wrist tether strap

- Always use the wrist tether strap to stop the pram/stroller rolling away.



What now?
Refer to the Bassinet
Manual.



WIN

with #babybeeprams

We love nothing more than seeing our Babybee babes out and (buzzing) about on daily adventures.

Tag us in your pics, on **Facebook** or **Instagram** for your chance to win a prize each month and be featured on the official Babybee social media accounts:
@babybeeprams



babybee

Designer style.
Unbeatable value.



Babybee prams



babybeeprams



hello@babybeeprams.com.au

Model: 2019 **ROVER**. Version: 1 - November 2018. Information subject to change. Please see website for current version.

[babybeeprams.com.au](https://www.babybeeprams.com.au)