

Error code summary

Error Code	Type	Toury Hight-step	Toury Step-thru	Transer Cargo
21	Current abnormal	Yes	Yes	Yes
22	Throttle abnormal	Yes	Yes	Yes
23	Phase abnormal	Yes	Yes	Yes
24	Hall sensor abnormal	Yes	Yes	Yes
25	Brake abnormal	Yes	Yes	Yes
30	Communication Abnormal	Yes	Yes	Yes
31	MOS damage	Yes	Yes	/
33	Key stickiness	Yes	Yes	/