



(back of switch)




Switch illuminates when pushed ON



Switch illuminates constantly when +12v source is applied

Switch Wiring Harness



N.C. (normally closed)
N.O. (normally open)
C (constant)
POS (positive 12V)
GND (negative 12V)

