

Welcome

Thank you for choosing our product!

We hope our product meets or exceeds your expectations. Should you have any questions, feel free to contact the seller including your contact information (name, phone number). Our customer representative will contact you soon.

We suggest that you keep this manual in a safe place. It contains essential information regarding the operation of your chair.


Contents

--General Warnings/	2
--Specific Warnings/	3
--Parts/	4
--Assembly Steps/	5/6/7/8/9
--Remote control	9
--Cleaning/ General trouble-shooting guide	10/11

General warnings

- Indoor use only.
- Ensure that only one person uses this chair at a time.
- Do not dry wet areas with hair dryers, etc.
- Do not over expose the leather to sunlight.
- Do not attempt to leave the chair while in the recline position.
- Take care to avoid sharp objects coming into contact with the chair such as needles, pins, scissors, etc.
- Do not leave the chair in the UP or DOWN position when not in use.
- Do not drag the chair when moving or lifting as this may cause damage to the lifting mechanism and trap the cables.


Caution!



The rise/recline of the footrest is supported by a scissor mechanism, so do not leave children or pets unsupervised or directly around the chair due to the potential risk of trapping by the mechanism. Also take care to avoid trapping clothing, blankets, fingers etc.

Specific Warnings

- Maximum loading capacity 300 lbs!
- Do not route any cable under the chair or through any moving part of the chair, as there is a risk of the cable being damaged which could cause an electric shock.
- Do not use the chair with an electric blanket.
- Do not move the chair if the power cable is connected to the outlet.
- Make sure no objects are in the way of the movement of the chair.
- Avoid any spillage of liquid and water on to the electrical system.
- Only use authorized accessories for the chair.
- If the chair becomes damaged, unplug and contact the seller for service.
- Keep all electronics away from moisture and extreme temperatures.
- Do not step on the armrests or footrest.
- Make sure cables away from chair base.




Specific Warnings
Please make sure there is enough distance between the wall and the chair back BEFORE fully reclining, to avoid damage to the chair.

Parts

The first box contains the following parts:

A: Accessory package



This package is inside the chair base and contains

1 Motor power cord




3 A wrench




4 Two castors




2 Transformer




B: Chair base & controller




C: Pillow




The second box contains the following parts:



D: Right ear



E: Right arm & left arm




F: Chair back


5

Assembly Steps

Step 1. Level the chair base




Step 2. Assemble the chair hands.





- a. Align the locking clip .
- b. Push the arm down evenly with both hands to the bottom.

6


Step 3 .Arrange the position of controller.




- a. Connect power cord and press this e button to lift chair in the highest position as show above.
- b. Customer can choose to place the controller on the left or right side of the chair according to their preference as show below.



Step 4. Lock castors on rear of chair.




Installation diagram




- a.Lay the chair base flatly as shown below.
- b.Fasten the castors with a wrench.

Step 5. Assemble the chair back.




- a.Align the locking clip.
- b.Slide the backrest into the chair base.

Step 6. Assemble the chair ears.




- a.Align the locking clip.
- b.Press the ear evenly with two hands to bottom.

Step 7. Connect cords.




- a.Connect the lumbar support cords as is shown above.




b. Connect power cord & transformer & extension cord as is shown above.

(power cord and transformer have been placed in the accessory package which had been tied inside the chair base!)

Remote control



- a) Lifts/Closes backrest.
- b) Lowers/Opens backrest.
- c) Opens lumbar support.
- d) Closes lumbar support.
- e) Lowers/Closes footrest and lifts chair.
- f) Lifts/Opens footrest and lowers chair.



Warm tips

This pillow is recommended when lying down on this chair it will help to support your body and make you more comfortable during sleep.

Cleaning

Follow these four quick steps to clean a breathable leather / fabric couch:

1. Wipe down the chair using a microfibre cloth
2. Wipe over using a damp cloth
3. Use eco-friendly soap
4. Wipe over using a dry rag.

General trouble-shooting guide.

How can I ask for help when something goes wrong with my product?

- Click contact link,send us an email,please include:
1. Brief problem description.
 2. Contact info. (phone number,email)
 - 3.Video or pictures demonstrating problem.

What if my lift chair does not work at all?

- 1.Make sure outlet is turn on and has electricity.
- 2.Ensure chair plug in outlet.
3. Make sure there is no cable damages.

The footrest cannot be fully raised.

The motor that controls the footrest needs to be replaced(the motor can be replaced very easily , the seller will provide an installation video if needed.)

Noises

All motors hum and vibrate slightly. This is normal. There are many moving parts and you may hear noises when operating the chair. However, if the noise is excessive, contact a customer service representative.

Thank you for choosing our product!