Cleanskin Digital Shock Pump User Manual


Remove the battery insulation sheet before use (fig 1)


Button Functions

1. **Button "A"** \rightarrow Power/Change units (PSI \rightarrow BAR \rightarrow KG/CM²)

Operation Mode Start-Up

- 1. Manual start-up → Press **Button "A".**
- 2. Automatic start-up → When pressure is above 5 psi the digital gauge will turn on automatically.







Trouble shooting

To reset the gauge press and hold Button A for 9 seconds to return the gauge to zero(0). (fig 2)


Battery Replacement

- ①Unscrew the 4 screws that are on the back of the gauge base
- ②Lift out the gauge cap
- 3 Take out LCD digital gauge
- ④ Open battery cap and replace the new 3V battery(CR2032). Please note that the positive pole (+) should face towards the battery cap and be inserted correctly.
- ⑤ Please make sure the O-ring in the bottom of the gauge is still there when replacing the battery











Battery Disposal

- Please ensure safe disposal of discharged button/coin batteries immediately.
- Place sticky tape around both sides of the battery and dispose of it immediately in an outside bin, out of reach of children, or recycle safely.



www.cleanskinmtb.com