

RF RENOVATION FACTORY



ASSEMBLY INSTRUCTIONS



PARTS

A	0	P	Pillar Cup	3
В	0		Glass Chimney	3
С		متآلت	Metal Frame	1

Unscrew the pre-fitted pillar cup, insert glass, and re-tighten pillar cup. Warning: To avoid cracking of glass, do not over - tighten pillar cup.