



STEP 3 Open Connector : Open the connector attached to the wire. Loose the cord grip of the canopy. Insert the wire through ceiling canopy. Attach the connector back to the wire.



STEP 4 Mount the Ceiling Canopy : Attach main wire to the connector. Attach the brown coloured wire to phase, blue coloured wire to neutral and green yellow coloured wire to earth. Fix the ceiling canopy to the mounting plate as shown below, and tighten with screw.



Assembly and Installation Instructions

Caution :

- BEFORE INSTALLING FIXTURE, MAKE SURE THE POWER TO THE CIRCUIT IS TURNED OFF AT THE MAIN FUSE BOX / CIRCUIT BREAKER UTILITY BOX.
- DO NOT INSTALL INTO A CEILING THAT CONTAINS RADIANT HEATING.

Important Safety Instructions :

- The ceiling screw anchors / screw are meant for drywall ceiling mounting only.
- The installation is not to be made on a radiant-heating ceiling.
- These instructions are provided for your safety. It is very important that they are read carefully and completely before beginning the assembly and installation of this lighting fixture.
- We strongly recommend that a professional electrician install all direct wire fixtures.
- This product must be installed in accordance with the applicable installation codes by a person familiar with construction and operation of the product and the hazards involved.
- The lighting fixture is meant for indoor use, dry locations only. It must be connected only to 3-wire, single-phase electrical supply systems (provided with Ground wire or equivalent protection system).
- For your safety, it is strongly recommended that two people install the lighting fixture.
- To avoid the risk of fire, do not exceed the recommended wattage.
- **Save these instructions.**

















Warning :


- To reduce the risk of fire, electrical shock or personal injury, always turn off light fixture and allow it to cool prior to replacing light bulb.
- Do not touch bulb when fixture is turned on. Do not look directly at lit bulb.
- Keep flammable materials away from lit bulb.

Pre-assembly :

- Remove all parts carefully and hardware from box along with any plastic protective packaging.
- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts
- For your safety and convenience, assembly by two people is recommended.

Parts Included :


A			Screw Anchors (Hardware Bag)	2
B			Screw Hardware Bag	2
C			Screw	2
D			Mounting Plate	1
E			Ceiling Canopy	1
F			Connector	1
G			Cord Grip	1
H			Glass Body	1




Assembly and Installation Instructions :

SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER!
Carefully unpack all fixture parts and hardware and lay out them on a clear workspace.


STEP 1 Unscrew Mounting Plate : Disassemble the mounting plate from the ceiling canopy as shown below.




STEP 2 Installing Mounting Plate : Take out the main wire from the hole of mounting plate. Install the mounting plate to the ceiling using the screw anchors. Align with the two holes of the ceiling. Tighten the screw.



STEP 5 **Adjusting Glass Body Heights :** Loosen the cord grip of the canopy. Adjust the wire height & tighten cord grip.




STEP 6 **Assemble the bulb :** Attach bulb to holder.



STEP 7 Restore power to junction box and test fixture.

STEP 8 Now your product is ready for use.



Final product image.

CLEANING & CARE

- Dust regularly with a dry cloth.
- Do not use abrasive cleaners.
- Do not use chemical cleaners.
- Retain these instructions for reference.

