




reddot award 2020
winner

CheerPod




产品简介


CheerPod是一款超小巧、可贴身携带的输入设备，同时又是一款将鼠标、触控板、PPT翻页笔合而为一的功能强大的产品。其独有的空中操控模式，将给您带来独一无二的触控体验！




产品清单



CheerPod x 1




数据线 x 1



使用手册 x 1

功能简介



关机



桌面模式
模式切换



空中模式

灯光指示



	功能	LED 灯状态
电源	充电	红灯呼吸
	满电	绿灯常亮
蓝牙	搜索	蓝灯呼吸
	已连接	蓝灯熄灭
激光	激光发光	蓝灯常亮
手指	四指	黄灯常亮

长按中键

开机并保持
长按 2 秒

蓝灯闪烁
两次

尽情
使用吧

点击
“链接”



主机可搜到
“CheerPod”

重置蓝牙并连接到新设备






注：会擦除连接过的设备

连接方式

Mac连接方式

打开“系统偏好设置”，选择，打开蓝牙搜索，搜索到“CheerPod”，选择连接即可。

Windows连接方式

选择“开始”，选择“设置”，选择“设备”，打开蓝牙开关，选择添加蓝牙设备，选择“蓝牙”选项，在“添加设备”页面，即可搜索到“CheerPod”。

iPad/iPhone连接方式

打开“设置”->“蓝牙”->搜索设备即可连接“CheerPod”。在已连接的情况下，若不显示鼠标指针，则可以通过打开“设置”->“辅助功能”->“触控”->“辅助触控”来开启光标。此时关闭“辅助触控”，鼠标指针依旧可以正常显示。









Android连接方式

打开“设置”->“蓝牙”->打开蓝牙并搜索，即可发现CheerPod设备，点击连接即可。

桌面模式

手势操作	Mac/Macbook	Windows	iPad/平板
按压左侧 	左击	左击	左击
按压右侧 	右击	右击	右击
按压中键并上下移动 	滚动	滚动	滚动
双指相向移动 	放大/缩小	放大/缩小	放大/缩小
三指轻击 	快速查询	/	/
三指轻击两次 	打开启动台	/	/
四指左右拖动 	多桌面切换	多桌面切换	多桌面切换
四指上下拖动 	多桌面控制	多桌面控制	多桌面控制

空中模式

手势操作	Mac/Macbook	Windows	iPad/平板
轻触设备 	左击	左击	左击
长按底部 	右击	右击	右击
按压顶部按键 	下一页	下一页	下一页
按压底部按键 	上一页	上一页	上一页
滑动左侧 	纵向滚动	纵向滚动	纵向滚动
滑动顶部 	横向滚动	横向滚动	横向滚动
双指相向移动 	放大/缩小	放大/缩小	放大/缩小
双指左右滑动 	多桌面切换	多桌面切换	多桌面切换


空中模式

手势操作	Mac/Macbook	Windows	iPad/平板
双指上下滑动 	多任务控制	多任务控制	多任务控制
三指单次轻击 	快速查询	/	/
三指轻击两次 	打开启动台	/	/
按压中键 	激光指示	激光指示	激光指示
轻击后移动 	选择/拖拽	选择/拖拽	选择/拖拽

备注:

如果您的Mac系统不支持“打开启动台”功能，请参照以下步骤来启用此功能

- 1、打开“系统偏好设置”
- 2、在搜索栏中输入“键盘快捷键”
- 3、选择“启动台和程序坞”与“显示启动台”选项卡
- 4、此时按压fn+F4键，系统将显示如右图



品名: CheerPod

产品型号: CHP01

品牌商: 北京奇点跳跃科技有限公司

地址: 北京市海淀区中关村东路8号东升大厦

网址: www.cheerdots.com

产品执行的国标: GB26245-2010-T计算机用鼠标器通用规范

注意事项

请勿自主拆卸和维修电子部件和电池

产品的运行温度范围为-10℃ (14°F) 至40℃ (104°F)

建议每三个月对电池充一次电, 以防止过量放电



警告: 当激光打开时, 不要直视激光束

防止对眼睛造成伤害! 请勿指向他人眼睛

联系我们

如果您对售后服务有任何要求, 请随时与我们联系。


官网: www.cheerdots.com

Your CheerPod at a glance


CheerPod is an ultra-thin and super portable device which you can carry around easily. It's such a powerful device that it combines mouse, touchpad and laser pointer all in one! You can connect to any devices for seamless control anytime, anywhere!




What's Inside



CheerPod x 1




USB x 1



Manual x 1

Basic Operations



Off



Ground Mode

Mode Switch



Air Mode

Indicator Light



	Function	LED state
Power	Charging	Red breathing
	Charged	Green on
Bluetooth	Broadcasting	Blue breathing
	Connected	Blue off
Laser	Laser on	Blue on
Finger	Four finger	Yellow on

Press & hold
middle button



Turn on device &
hold 2 seconds



Blue LED
blinks twice



Enjoy your
CheerPod!



Connect
to host





“CheerPod” can
be found by host

Reset Bluetooth & Connect to New Host




Note: will erase all bounded devices

Connection

Connection with MacOS

Open "System Preferences"  , choose "Bluetooth"  , turn on bluetooth and search, you will see "CheerPod" in searching bar, click to connect with your CheerPod.

Connection with Windows

Click "Start" icon  , then open "Settings"  , select "Devices"  , turn on the Bluetooth switch  , then click "Add Bluetooth or other devices"  , choose "Bluetooth", then you can search and connect with "CheerPod" on the "Add a device" page

Connection with iPad/iPhone

Open "Settings" -> "Bluetooth" -> Search for devices to connect with "CheerPod". If the mouse cursor is not shown on the screen, you can turn on the cursor following below steps: "Settings" -> "Accessibility" -> "Touch" -> "AssistiveTouch", then mouse cursor will be displayed on the screen. Mouse cursor can still be shown normally when you turn off "Assistive Touch" after that.









Connection with Android

Open "Settings" -> "Bluetooth" -> turn on Bluetooth and search devices, then you can find "CheerPod" in searching list, click & connect.






Ground Mode

Gestures	Mac/Macbook	Windows	iPad/Tablet
Left Click 	Left Click	Left Click	Left Click
Right Click 	Right Click	Right Click	Right Click
Mid-click + Move Up/Down 	Scroll Up/Down	Scroll Up/Down	Scroll Up/Down
Pinch with 2 Fingers 	Zoom In/Out	Zoom In/Out	Zoom In/Out
Tap with 3 Fingers 	Look Up/ Date Detectors	/	/
Double-tap with 3 Fingers 	Launcher	/	/
Left/Right Drag with 4 Fingers 	Switch between Multi-tasks	Switch between virtual desktops	Switch between Multi-tasks
Drag Up/Down with 4 Fingers 	Open/Close Mission Control	Show Desktop/Windows	Open/Close Mission Control

Air Mode

Gestures	Mac/Macbook	Windows	iPad/Tablet
Tap On Surface 	Left Click	Left Click	Left Click
Long Press Botom 	Right Click	Right Click	Right Click
Press Top Button 	Next Page	Next Page	Next Page
Press Bottom Button 	Previous Page	Previous Page	Previous Page
Scroll Left Bar 	Scroll Up /Down	Scroll Up /Down	Scroll Up /Down
Scroll Top Bar 	Scroll Left /Right	Scroll Left /Right	Scroll Left /Right
Pinch with 2 Fingers 	Zoom In/Out	Zoom In/Out	Zoom In/Out
Slide Left/Right with 2 Fingers 	Switch between Multi-tasks	Switch between virtual desktops	Switch between Multi-tasks


Air Mode

Gestures	Mac/Macbook	Windows	iPad/Tablet
Slide Up/Down with 2 Fingers 	Switch between Multi-tasks	Show Desktop/Windows	Switch between Multi-tasks
Tap with 3 Fingers 	Open/Close Mission Control	/	/
Double-tap with 3 Fingers 	Look Up /Date Detectors	/	/
Mid-click 	Laser Pointer	Laser Pointer	Laser Pointer
Double tap & move 	Select/Drag	Select/Drag	Select/Drag

Note:

If your Mac OS does not support the “Launchpad” feature , follow these steps to enable it

- 1、 Open “System Preference”
- 2、 Type “keyboard shortcuts” in the search bar
- 3、 Select “Launchpad & Dock” and “Show Launchpad”
- 4、 Press fn+F4 It will show like this:



Product Name: CheerPod

Product Number: CHP01

Company Name: CheerDots Co., Ltd

Company Address: 4th Floor, Block A, Dongsheng Building, No. 8
Zhongguancun East Road, Haidian District, Beijing, China

Official Website: www.cheerdots.com

Note

Device operating temperature range is $-10^{\circ}\text{C} \sim 40^{\circ}\text{C}$ ($14^{\circ}\text{F} \sim 104^{\circ}\text{F}$)

Recharging the CheerPod every 3 months is recommended, which will maximize the battery life span.



Warning Strong laser beam will do harm to eyes.

Do not look directly at the laser beam when laser turned on.

Do not point to other people's eyes.

Contact Us

If you have any requirements of after-sales service, feel free to contact us.

website: www.cheerdots.com