






(operating manual)


















Glass side panel installation: fix the glass side panel with 4 screws (as shown above)


Metal side plate installation: buckle the side plate and fix it with two screws







The power supply can be fixed by aligning the screw in the figure to the hole position

Note: different types of power supply, hole location may be slightly different, take the actual object as the standard







Support: ATX/M-ATX/ITX







To remove the front panel of the case, pull it by hand, firmly from the bottom of the panel



Fan Support: Front: 3 x 120mm (Included) Top: 2x 120/140mm (optional) Rear: 1x 120mm (optional)
Bottom: 2x 120mm (optional)



Radiator Support: Front: 240/360mm Rear: 120mm



Align the screw holes of the hard disk with the hard disk bracket and fix it with special screws.



2*HDD

Align the screw holes of the hard disk with the hard disk bracket and fix it with special screws.

