
## **ASS SLIDER**

ANTI STRAP SYSTEM FOR TOP TUBE BAGS





# A.S.S SLIDER (Anti Strap System)

provides strapless mounting for top tube bags with or without mounting bosses.

Provides a quick release function, ideal for keeping contents safe at cafe stops.

Works with bolt-on bags and many strap-on bags which can be converted. (see links on

(see links on website)







- · Slide on/off quick-release.
- No headtube strap required for small bags / bento boxes.
- · Large bags may require use of the headtube strap or ASS CLIP.







### **BIKE SLIDER - DIRECT MOUNT**




#### **BIKE SLIDER - ADHESIVE**

APPLY IN A WARM, DRY ENVIRONMENT. ENSURE SURFACES & HANDS ARE GREASE FREE.

#### REMOVE BY CENTLY HEATING WITH A HAIR DRYER.




Apply adhesive pad firmly pressing all areas.



Mark a centre line on top tube.



Slide onto bag. (Removal may require alot of force)



Place on bike. Mark a line at the front of the bracket.

Slide bracket off (may require alot of force)



Peel back film, align front edge and press firmly.

Ensure alignment, pull away the rest of the film and press firmly.



For non uniform and narrow tubes we advise to hold in place with tape whilst curing.

MEASURE TWICE, STICK ONCE! CURE FOR 24 HOURS.