

ECOSAM® Disinfectant Spray Gun

Visit www.ecosam.sg for the latest information



Specifications

Name: ECOSAM® Disinfectant Spray Gun. Item number: A9-03. Weight: 235 grams. LED light: Blue. Decibel: < 65dB. Rated power: 10W. Colour: White, Pink.	Material: ABS, PET, PC. Charging cable: USB-C. Charging current: 2.1A Charging voltage: DC 5V. Battery capacity: 1500mAh. Water bottle capacity: 300mL. Box package size: 85x144x170mm.
---	---

Functions

Spray ECOSAM® Disinfectant Cleaner. Use a 5V 2.1A power supply to charge. Use the USB-C cable in the box.	Recharge when the battery is flat. Recharge until red LED light switches off. 1 hour of spraying from 2 hours of charging.
---	--

Operations

Press the button for 2 seconds to start. Press the button for 2 seconds to stop.	Recharge when the battery is flat. Recharge until red LED light switches off.
---	--

Precautions

Do not use chlorine tablets that will damage the spray gun. Do not soak into water, drop from a height, or place any heavy objects onto it. Although it is inexpensive, this spray gun is not a toy and is intended for adult use only.	Weighing only 235 grams and retailing at a low price, the ECOSAM® spray-gun is a precision optoelectronic and fluid-mechanic equipment made of recyclable, easy-to-carry, portable, light-weight, light-duty plastic & affordable parts. Keep the nozzle dust-free and clean.
--	--

Google: ECOSAM Spray Gun is Easy to Repair video <https://youtu.be/z6fjy0bkklc>

Nozzle. Battery.	Button light assembly. Pump.
------------------	------------------------------

Services

Inkjet Systems Pte Ltd. 56 Loyang Way 02-18. Singapore 508775.	Tel: 6333-3302. WhatsApp: 9011 2282. www.ecosam.sg
--	---