


Decorative Canopy
ASSEMBLY INSTRUCTIONS

Delta[™]
Children's Products

ADULT ASSEMBLY REQUIRED



***WARNING:** Discontinue use when baby starts to pull up and stand on its own to prevent pulling.


Canopy Parts

IMPORTANT! Please remove all parts from the package and identify them before assembly.



⚠ WARNING



This package contains small parts.
Keep away from children during assembly.
Adult assembly required.




(A) Decorative Canopy x 1





(B) Plastic Pole x 2




Canopy Assembly




- Gently bend each plastic pole to form half circle shape.



- Turn decorative canopy inside out.
- Find opening of mesh canopy sleeve.





Canopy Assembly



- Insert one of the plastic poles.
- Thread the pole halfway through the canopy sleeve.




- Insert the second plastic pole.
- Thread the pole halfway through the canopy sleeve.




- Join together 2 poles inside of the canopy sleeve.
- Join the other ends of the poles at the opening of the canopy sleeve.

POLES INSIDE CANOPY SLEEVE



POLES AT OPENING OF CANOPY SLEEVE

POLES AT OPENING OF CANOPY SLEEVE




POLES INSIDE CANOPY SLEEVE

Hanging Assembly



- Determine the location for hanging the decorative canopy.
- Make a hole with hammer & nail or use a drill—make sure the nail/drill bit is smaller than the closed end of the plastic anchor. You only need to go as deep as the anchor.

CEILING



- Tap gently until the anchor head is flush with the wall.
- Insert the screw hook into the anchor.
- Slowly & evenly tighten the screw into the anchor.

CEILING



**ENJOY YOUR NEW
DELTA CANOPY!**



Delta
Children's Products™

Customer Care
Tel. (212) 645-9033


114 West 26th St.
New York, NY 10001
www.deltachildren.com

Made in China




- Position the plastic anchor over the hole.
- Tap plastic anchor into the hole gently with the hammer
- *Plastic anchor is not necessary for wood beams.

CEILING



- Slide top of the canopy loop onto the screw hook.

CEILING



***WARNING: Discontinue use when baby starts to pull up and stand on its own to prevent pulling.**