WIRING for 33R877-0003-G1 (9 AMP)






POWER AT START + RUN POSITION FOR FUEL SOLENOID

GROUND

BLACK: REGULATOR GROUND

RED: DC POWER TO BATTERY + LIGHTS



YELLOW: AC POWER FOR REGULATOR


GRAY: POWER IN START + RUN POSITION FOR FUEL SOLENOID

DC REGULATED POWER TO

RED + ORANGE


RED: POWER TO BATTERY

ORANGE: POWER TO LIGHTS



BLACK: TO IGNITION COIL – GROUNDS IN STOP POSITION, OPENS IN RUN POSITION

Lights will be on when engine is running on dual circuit systems



BRIGGS & STRATTON 6-PIN WIRING HARNESS

PART NUMBER 790544



DC CONNECTOR TO RED +
ORANGE WIRE ON 6-PIN
CONNECTOR HARNESS





RED TO CHARGE BATTERY + ORANGE TO POWER LIGHTS

