



Thank you for choosing NPET! Please read this user manual carefully and save it for future reference.


Package Contents

- 1 x Wired Gaming Keyboard
- 1 x User Manual
- 1 x Keycap Puller

Specification of Keyboard

Connection	USB Wired
Dimensions	439*134*35mm/17.2*5.2*1.3in
Net weight	725g
Layout	104 Keys
Cable Length	1.7m
Compatibility	Windows, Mac OS

Hardware Basics




Front Layout

1

K10 WIRED

Membrane Gaming Keyboard

Wired Gaming Keyboard Operating Instructions



Rear Layout

LED Indicators(From left to right)

Num: "On" means numeric keys are enabled; "Off" means numeric keys are disabled.
Caps: "On" means letters will be typed uppercase; "Off" means letters will be typed lowercase.
Scroll: "On" means moving your arrow keys will scroll the entire page; "Off" means arrow keys that move you will jump in the cell.
Win: "On" means the win key is locked; "Off" means the win key is unlocked.

Function Introduction

- With standard USB interfaces, the keyboard can be used on computers without any software or driver installation.
- 26 keys non conflict: Q, A, Z, W, S, X, E, D, C, R, F, V, T, G, B, M, Space, ↑(UP), ↓(Down), ←(Left), (Right)→, Tab, Ctrl-L, Shift-L, Alt-L, Capslock.
- Construction

Keycap
Previous to light cover
Backlight source
Steelplate
Bottom cover

2

Backlit Mode Introduction

--- Turn On/Off Backlit / 3 permanent lighting modes

+ / --- 7 Colors Backlit Breathing

Light Function Adjustment

+ --- Brightness increasing

+ --- Brightness decreasing

+ --- Increase backlit breathing frequency

+ --- Decrease backlit breathing frequency

Multi-media keys(FN+F1~F12)

FN+F1		Media player	FN+F7		Play/Pause
FN+F2		Volume down	FN+F8		Next track
FN+F3		Volume up	FN+F9		E-mail
FN+F4		Mute	FN+F10		Home
FN+F5		Stop	FN+F11		Scroll Lock
FN+F6		Previous track	FN+F12		Calculator

3

Other Functions of FN Key Combination


+ --- Win Key Locking Control

Press FN+Win to lock the function of Win key.
Press FN+Win again to unlock the function of Win key.

+ --- Switch WASD keys to arrow key

Press FN+W to switch WASD to arrow keys.
Press FN+W again to WASD keys main function recovery.

Connect your NPET device to the USB port of your computer



Note:
The keyboard can type normally on the ios system, but combination functions cannot work on the ios system, which does not mean that the keyboard is damaged, only the problem of system compatibility.

4

FAQ

- If the keyboard doesn't respond, please check if the keyboards USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on the computer.
- If you spill liquid on the keyboard, please remove keyboards USB cable from the computer immediately. Wipe up excess liquid and put the keyboard in a warm place (for instance, under a lamp) to let the keyboard dry naturally before using again.

How to care for your keyboard

- Wire safety**
Avoid bending it. Don't place anything heavy on it to avoid stress, which can cause cuts or breakage.
- Avoid Liquids**
The spilling of liquids is very harmful. It can damage your keyboard's internal circuit or can cause malfunctioning of the keyboard.
- Avoid eating while sitting on the keyboard**
Don't eat while sitting near the keyboard. When you do so, small pieces of your food can fall and enter inside the circuit, which can result in stopping one or more keys from functioning.
- Soft key press**
Try to press the keys as softly as you can. It helps in the long life of keys and characters printed upon them.
- Cover after Use**
Cover it to avoid dust particles. It can harm the circuit under the keys, which results in the non-functioning of one or more keys.
- Clean it properly**
Use a can of compressed air to clean between the keys. Moisten a cotton cloth or paper towel with rubbing alcohol and use it to clean the tops of the keys. Do not pour alcohol or any other liquid directly onto the keys.

Dear user

Thank you for choosing NPETech, to protect your rights and for better customer service, we ask that you note our warranty rules.

- Within the guarantee period, the repair is guaranteed for failure due to electrical circuit problems. Man-made damages, such as disassembly, hard impacts, submersion into the water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.
- Consumable parts (such as foot stick) and spare parts replacement are not included in our warranty.

5



NPETをお選びいただき、ありがとうございます!ご使用前に、取扱説明書をよくご覧下さい。今後、使用されるために、この取扱説明書を保ってください。


パッケージの内容

- 1 x 有線のゲーミングキーボード
- 1 x 取り扱い説明書
- 1 x キーキャッププラー

キーボードの仕様

接続	USB有線
寸法	439*134*35mm/17.2*5.2*1.3in
正味重量	725g
レイアウト	106キー
ケーブルの長さ	1.7m
互換性	Windows, Mac OS

キーボードのレイアウト




前のレイアウト

1

K10 有線

メンブレン式ゲーミングキーボード

有線ゲーミングキーボードの取り扱い説明書



後ろのレイアウト

LEDインジケータ(左から右へ)

Num: 「オン」は、数字キーが有効になっています。「オフ」は、数字キーが無効になっています。
Caps: 「オン」は、文字が大文字で入力されます。「オフ」は、文字が小文字で入力されます。
Scroll: 「オン」は、矢印キーを動かすとページ全体がスクロールします。「オフ」とは、移動する矢印キーがセルにジャンプします。
Win: 「オン」は、Winキーがロックされています。「オフ」は、Winキーのロックが解除されています。

機能の説明

- 標準USBインターネットを備えたキーボードは、ソフトウェアやドライバーをインストールせずともコンピューターにて使用できます。
- 26キー抗衝突:Q, A, Z, W, S, X, E, D, C, R, F, V, T, G, B, M, Space, ↑(UP), ↓(Down), ←(Left), (Right)→, Tab, Ctrl-L, Shift-L, Alt-L, Capslock.
- 構造

キーキャップ
光を通すカバー
光源
鉄板
ボトムカバー

2

バックライトモードの説明

--- 一点灯/消灯 / 3種固定模式的バックライトモード

+ / --- 7色呼吸モード

バックライトを調整

+ --- 光度を上げる

+ --- 光度を下げる

+ --- 呼吸速度を上げる

+ --- 呼吸速度を下げる

マルチメディアキー (FN + F1 ~ F12)

FN+F1		メディアプレーヤー	FN+F7		再生/一時停止
FN+F2		音量を下げる	FN+F8		次の曲
FN+F3		音量を上げる	FN+F9		Eメール
FN+F4		ミュート	FN+F10		ホーム
FN+F5		停止	FN+F11		スクロールをロック
FN+F6		前の曲	FN+F12		計算機

3

FNキーと組み合わせる他の機能


+ --- Winキーをロック

FN+Winを押すと、Winキーの機能をロックします。
FN + Winをもう一度押すと、Winキーの機能が解除します。

+ --- WASDキーを矢印キーに切り替える

FN + Wを押すと、WASDを矢印キーに切り替えます。
FN + Wをもう一度押すと、WASDキーの主な機能を回復します。

NPETのデバイスをコンピューターのUSBポートに接続



ご注意:
iOSシステムで、キーボードが正常に入力できますが、組み合わせ機能を効かない恐れがあります。キーボードが不具合がないで、システム互換性の制限です。

4

よくある質問

- キーボードが応答しない場合、キーボード・インターフェイスがコンピューターのUSBポートに正しく差し込まれているかどうかを確認し、又はキーボード・インターフェイスをコンピューターの別のUSBポートに差し込むよう試すこと。
- 気が付かない打ちにキーボードに液体を撒いた場合、キーボード・インターフェイスをコンピューターから抜き出し、キーボード上の液体をふき取った後、キーボードを日光の下に置いて晒し乾かし、キーボード上の液体が完全に蒸発したのを確認してから使用すること。

キーボードのお手入れ方法

- 電線の安全性**
曲げないでください。ストレスで切り傷や破損などを避けるように、重いものを載せないでください。
- 液体を避けてください**
キーボードに液体を溢れると、キーボードの内部回路を損傷したり、キーボードの誤動作を引き起こしたりする恐れがあります。
- キーボードの上で食べることは避けてください**
キーボードの近くに座って食事をしてください。食べ物の小片が落下してキーボードの回路内に入り、1つまたは複数のキーが機能しなくなる恐れがあります。
- 柔らかい手に押しつけてください**
キーキャップの文字やキーの寿命を延ばすために、キーをできる限りに柔らかい手に押しつけてください。
- 使用后、カバーをしてください**
ほこりがキーの下の回路に損傷を与え、1つまたは複数のキーが機能しなくなる恐れがあります。ほこりを避けるように、キーボードにカバーをしてください。
- 適切に清掃**
キーボード掃除機でキーの間を掃除してください。消毒用アルコールで綿布またはペーパータオルを湿らせ、キーキャップの上部をきれいにします。キーに直接アルコールやその他の液体を注がないでください。

お客様

NPETechの製品をお買い上げいただき、ありがとうございます。お客様の権利を保護し、より良いサービスを提供するために、お客様の権利を保護し、より良いサービスを提供するために、以下の「保証規定」をご確認ください。

- 保証期間内にて、電気回路の問題に起因する修理が保証されます。分解、衝撃、水没、間違った電流や電圧入力などの人災、洪水、地震などの自然災害により起こった故障は、対象外となります。
- 消耗品(フットスティックなど)とスペアパーツの交換は、保証の対象外となります。

5