



Connections			
1	Bridge north start	10	Jack ground
2	Bridge north finish	11	Jack positive
3	Bridge south start	12	Ground (neck pickup)
4	Bridge south finish	13	Neck south finish
5	Ground (bridge pickup)	14	Neck south start
6	Switch (bridge)	15	North north finish
7	Switch (output)	16	Neck north start
8	Switch (neck)	17	String ground (from tailpiece)
9	Ground (switch)		





Basic Controls	
Neck Volume	Splits Neck HB
Neck Tone	Series/Parallel
Bridge Volume	Splits Bridge HB
Bridge Tone	Phase Reverse

