

customerservice@arnsberg.com

www.arnsberg.com

### **Parts Included**

Wire Connector






Mounting Strap

Mounting Screw

AD



**Outles Box Screw** 





### **CSA / UL SAFETY REQUIREMENTS**

CSA/UL requires that these IMPORTANT SAFETY INSTRUCTION be listed:

Before starting installation of this fixture or removal of a previous fixture, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box.



□ Consult a qualified electrician if you have any electrical questions or need to replace the driver.


### **Care Instructions**

Arnsberg suggest using only micro fiber cleaning cloth to clean this fixture. If required, a slightly damp cleaning cloth may be used to spot clean. Do not use common household cleaners on this fixture, as the final finish may be damaged as a result. Enjoy your new Arnsberg fixture.

# Arnsberg.com

## ASSEMBLY INSTRUCTIONS CAYMAN 829210407

**Mounting Instructions:** 



### **Assembly Instructions:**

1. Mount the Mounting Strap (#4) to the Outlet Box (#3), using the Outlet Box Screw (#5).

2. Connect the ground wire from the fixture to the ground wire from the Outlet Box (#3). Connect the white wire from the fixture to the white wire (neutral wire)from the Outlet Box (#3). Connect the black wire from the fixture to the black wire (live wire) of the Outlet Box (#3).Cover the connections using the Wire Connectors (#2).Wrap the wire connectors with electrical tape for a more secure connection. Position the wires back inside the Outlet Box(#3)Note:If you have electrical questions,consult your local licensed electrician.

3. Place the Canopy(#1)over the Outlet Box (#3), place the Mounting Screws(#6)to the holes of the Canopy (#1) and the Outlet Box (#3). Screw the Mounting Screws (#6) to secure the Canopy (#1)

4. Installation in complete. Turn on the power at the circuit breaker of the fuse box. Turn the light switch on to activate the fixture.