

customerservice@arnsberg.com www.arnsberg.com

## ASSEMBLY INSTRUCTIONS

# CLARIMO 659011801

#### Parts Included:

**Mounting Strap** 



**Outlet Box screw** 



Wire Connector



Mounting Screw





### **CSA / UL Safety Requirements**

CSA/UL requires that these IMPORTANT SAFETY INSTRUCTION be listed:

☐ Before starting installation of this fixture or removal of a previous fixture, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box.



☐ Consult a qualified electrician if you have any electrical questions or need to replace the driver.


#### **Care Instructions**

Arnsberg suggests using only a micro fiber cleaning cloth to clean this fixture. If required, a slightly damp cleaning cloth may be used to spot clean. Do not use common household cleaners on this fixture, as the final finish may be damaged as a result. Enjoy your new Arnsberg fixture.



www.arnsberg.com

#### Mounting Instructions



# ASSEMBLY INSTRUCTIONS CLARIMO 659011801

#### **Assembly Instructions**

- 1. Screw the two mounting screws (#6) into the mounting strap (#4). Mount the mounting strap (#4) to the outlet box (#3) using the outlet box screws (#5). Make sure the heads of the mounting screws (#6) are facing outside when the mounting strap (#4) is attached to the outlet box (#3).
- 2. Connect the ground wire from the fixture to the ground wire from the outlet box (#3). Connect the white wire from the fixture to the white wire (neutral wire) from the outlet box (#3). Connect the black wire from the fixture to the black wire (live wire) from the outlet box (#3). Cover the connections using the wire connectors (#2) Wrap the wire connections with electrical tape for a more secure connection. Position the wires back inside the outlet box (#3). Note: If you have electrical questions, consult your local licensed electrician.
- 3. Place the canopy (#1) over the outlet box (#3). Allow the heads of the mounting screws (#6) to come out through the large ends of the keyholes. Screw the mounting screws (#6) to secure the canopy (#1).
- 4. Before completing installation, place the lampshade on the corresponding rotary button of the chassis, and lock the lampshade according to the arrow direction.
- 5.Installation is complete. Turn on the power at the circuit breaker or fuse box. Turn the light switch on to activate the fixture.