
CTQLIGHTING

RING PENDANT

Installation Guide



Please handle with care and wear gloves at all times during assembly and installation to avoid damaging components.

+44 (0) 20 7686 8700 ctolighting.co.uk sales@ctolighting.co.uk

СТО


TECHNICAL

Bulb Holder

240v - 1 x E14 120v - 1 x E12 (no bulbs supplied) Wattage 6w 2700k - LED ONLY **Weight** 2kg (4.4lbs)

PARTS & COMPONENTS

A. 1 x Mounting plate B. 1 x Ceiling rose and Ring pendant C. 4 x Screws




- All nuts and bolts required for assembling the light are included.

BEFORE INSTALLATION

ļ

СТО


Check that you have all components before starting the installation.
Installation must be carried out by a qualified electrician.
A minimum of two people is required to install a pendant light.
Check that the ceiling or wall fixings are suitable and strong enough to support the weight of the light fixture.
You will need the below specific tools for a successful installation.




1. 240V

- A. Securely fix the mounting plate to the ceiling in the correct position using fixings suitable for the surface you are mounting to (not supplied).
- B. Raise the pendant and make the electrical connections inside the ceiling box ensuring all wires are colour matched and the pendant is earthed correctly.

Bring the ceiling rose cover up to the mounted plate and secure with the four screws.







1. 120V

- **US** A. Fix the mounting plate to the junction box using suitable screws (not supplied).
 - B. Raise the pendant and make the electrical connections inside the junction box ensuring all wires are colour matched and the pendant is earthed correctly.


Bring the ceiling rose cover up to the mounted plate and secure with the four screws.





2. With the ceiling rose securely fixed to the ceiling, raise the pendant to access the lampholder.

Fit the bulb to the lampholder and carefully lower the pendant ensuring that it is sitting level.



Ð

MAINTENANCE

Cleaning

Dust using a dry lint-free cloth weekly or as required

Repairs Contact CTO Lighting Warranty Please visit www.ctolighting.co.uk/ pages/f-a-q for CTO warranty policy



+44 (0) 20 7686 8700

sales@ctolighting.co.uk