

LED Floor Lamp

FL12168

INSTALLATION SHEET

START FROM HERE


- Prepare everything in a clear area.
- Read instructions carefully before you start assembly.
- Keep this instruction sheet for future reference.

Technical Support: 1-855-855-8926

Please Note:

- This Kuzco LED fixture comes with pre-wired LED module(s)
- Unless instructed, Do Not touch any part of the LED module(s) as any unnecessary contact with the module could cause permanent damage
- Touch Dimmer
- 120V input

- 1.** Remove the fixture from it's original packaging
- 2.** Attach fixture head (1a) to rod (1b)
- 3.** Insert coaxial connector (1c) into rod (1b) and thread clockwise to secure. Repeat for all rods and secure bottom rod into fixture base (3a)
- 4.** Plug driver (4a) into outlet
- 5.** Use hand to activate dimmer (2a). Touch and hold to dim, touch to turn on/off



KUZCO

19054 28th Avenue Surrey, BC Canada V3Z 6M3
T: 604 538 7162 TF: 1-855 85 KUZCO F: 604 538 7196
W: kuzcolighting.com
20240109