

## **LED Product Information and Warnings**

### **Important**

- Always disconnect the power before installing or replacing bulbs and before cleaning or other maintenance.
- Consult a qualified, licensed electrician to ensure correct branch circuit conductor.
- Please read all included assembly instructions and warnings carefully before installation. Contact
  Customer Service if you have any questions or concerns. Before installation, please confirm that the fixture
  is compatible with your supply voltage and dimming system, if present.
- LEDs are highly sensitive electronic devices, and must be treated with care. Do not open any factory sealed compartments, and avoid touching the LEDs with your hands or any object.
- Although all our fixtures are equipped with protective devices, LED fixtures are vulnerable to power surges
  and supply variations. Do not install LED fixtures on the same circuit as any motors, appliances, or HVAC
  systems.
- Do not remove or bypass any LED Driver or Transformer that is provided with the fixture, and do not replace or substitute with another power supply.
- Remote LED Driver or Transformer installation must be done by a licensed electrician and in accordance with local codes. Remote installations should be in an accessible location, as close to the fixture as possible.
- Fixtures must be wired in parallel on independent leads; do not "daisy chain" multiple fixtures together or wire them in series.
- All factory-made splices and connections must remain intact. LED circuits are carefully designed and built, and improper connections may damage the fixture.
- The ends of coaxial pendant cords have been precisely stripped and split at the factory and must not be field cut. Excess cord or cable should be neatly coiled and reserved in the fixture canopy.
- Any mounting hardware is provided for your convenience and should be used with discretion. Always use the appropriate hardware for the mounting surface.

©2015 SONNEMAN - A WAY OF LIGHT 1 of 2

# SONNEMAN®

### **Assembly Instructions**


7250, 7252


INSTRUCTIONS D'INSTALLATION

Radiance Series - 20" LED Sconce, 30" LED Sconce

### **Important**

- Always disconnect the power before installing or replacing bulbs and before cleaning or other maintenance.
- Consult a qualified, licensed electrician to ensure correct branch circuit conductor.
   Consulter un électricien qualifié pour vous assurer que les conducteurs de la dérivation sont adéquats.
- 1. Shut off power to the outlet box (A).
- 2. Make appropriate electrical connections using wire nuts:
  - a. Connect the LED driver's (B) live wire (black) to the live outlet box wire.
  - b. Connect the LED driver's (B) neutral wire (white) to the neutral outlet box wire.
  - c. Connect the fixture's ground wire (green or uncoated) to the ground outlet box wire. If no ground is present in outlet box, connect fixture's ground wire to the mounting plate (C) using the green screw (included).
  - d. Carefully place connections and LED driver (B) in outlet box (A).
- 3. Attach the mounting plate (C) to the outlet box (A), secure with outlet box screws (D). Use anchors (E) and screws (F) to secure ends of mounting plate to mounting surface.
  - **For Wet Location Use:** Fixture must be installed in a vertical position and mounted minimum 4' above the ground.
- 4. Install the back plate (G) to the mounting plate (C). Secure with mounting screws (H) using included Allen wrench (I).
  - **For Wet Location Use:** Included gaskets must be used under the mounting screws.
- For Wet Location Use: Place a small bead of silicone or water proof caulk (not included) around the back plate (G) where it comes into contact with the wall.
- **6. For Wet Location Use:** Using the included Allen wrench (J), remove and discard the set screw (K) from the bottom end of the fixture to allow any accumulated moisture to drain.
- 7. Restore power to the fixture.





#### Note

- Fixture 7250 is dimmable with Electronic Low Voltage (Trailing-Edge) and Incandescent (TRIAC) type dimmers only.
- Fixture 7252 is dimmable with Electronic Low Voltage (Trailing-Edge), Incandescent (TRIAC) type dimmers, or 0-10V dimmers only.

### **Care Instructions**

- · Dusting: Use a clean, dry cloth.
- Cleaning: To protect the finish, avoid any harsh abrasives or chemicals.