

REGINA ANDREW

DETROIT

ITEM NO: 14-1056 Noble Floor Task Reading Lamp

PLEASE NOTE THAT IF ADJUSTABLE KNOB IS NOT LOOSENED BEFORE ADJUSTING THE HEIGHT, PERMANENT DAMAGE TO THE MECHANISM MAY OCCUR.

ASSEMBLY INSTRUCTIONS

1. Carefully remove all parts from box and remove all plastic covering from lamp parts.
2. Place the base on the floor. While holding the main tube upright, insert the small pins on the base into the holes on the bottom of the tube. Pull the cord from under the base, then tighten the nut with the wrench provided.
3. Adjust the height of the lamp by rotating the adjustable knob counterclockwise to loosen, then tight.
4. Slide the shade onto the socket cup.
5. Insert the proper bulb into the socket.
6. Insert the polarized plug into wall outlet, turn on switch and enjoy your new lamp.

CLEANING AND CARE:

Use a soft cloth only, do not use any chemical or abrasive cleaners.

IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one-way. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

Made in China

