


ASSEMBLY INSTRUCTIONS FOR YOUR CINCH TABLE LAMP



IMPORTANT SAFETY INSTRUCTIONS:

- * This lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do NOT alter the plug.
- * Do not use with an extension cord unless the plug from the lamp can be fully inserted into the extension cord receptacle.
- * Switch power off and remove plug from the wall outlet before replacing the bulb.
- * This lamp is UL rated for dry locations.

ASSEMBLY INSTRUCTIONS

NOTE: Do not connect electricity until lamp is fully assembled.

1. Unpack all parts and remove packing materials. Place lamp base on a level surface.
2. Remove flange (A) and socket cover (B) from threaded socket (D).
3. Place shade (C) onto threaded socket (D).
4. Place socket cover (B) over threaded socket (D) and thread flange (A) back onto threaded socket (D) to secure shade to fixture.
5. Install one 60W MAX. Type A, medium base bulb into threaded socket (D).
6. Move shade into desired position by gently swiveling side to side at joint (F).
7. Insert polarized plug (G) into wall outlet.
8. Control power to the fixture by operating a full range dimmer (E) located inside top shade.