

MONETA BATTERY POWERED LAMP

SLTB27127x

General Product Information



Safety Information

SAVE THESE INSTRUCTIONS!

CAUTION-RISK OF FIRE


This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

USE MINIMUM 90°C SUPPLY CONDUCTORS.



Turn off electrical current at the source before working with any lighting fixture or portable lamp.

Install and use this product in adherence with local electrical codes and regulations.



INSTRUCTIONS

1. Carefully remove the fixture from the packaging and plug-in with supplied USB cord/plug. Ensure that the product is fully charged before initial use and turn the fixture on.
2. Pay attention to the indicator light, located next to the USB-C port:
 - a. Solid Red: The fixture needs to be charged.
 - b. Green Flashing: The fixture is currently charging.
 - c. Solid Green: The fixture is fully charged.

Note: It will take approximately 6 hours to fully charge the fixture.

3. Use the touch-sensitive switch to change the brightness setting.

CAUTION: Ensure that the silicone USB cover/plug is re-installed after charging to keep dust/moisture out of USB plug area.