


BBL3006

ASSEMBLY & INSTALLATION GUIDE



INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

1. Loosen thumbscrews (G).
2. Insert lamp stem (I) into glass base (J), letting glass cap (H) covers top groove of glass base (J), and tighten thumbscrews (G). DO NOT OVER TIGHTEN! Pull the wire until tight.
3. Remove threaded ring (E) from socket cover (F).
4. Attach bottom ring of harp (D) over top threaded section of (F), and secure with threaded ring (E).
5. Remove finial (A), flat washer (B) from harp (D).
6. Attached lamp shade (C) over top bolt attach on top of harp (D), and follow with flat washer (B), screw finial (A) onto the bolt to secure shade (C) to harp (D).
7. Insert light bulb into upper socket.
8. Insert light bulb into lower socket inside of glass base.
9. Remove protective plastic (L) from electrical plug (K).
10. Plug lamp into electrical outlet.
11. ADJUSTMENT INSTRUCTIONS
 1. Loosen adjustment knobs at both sides of harp (D).
 2. Adjust harp (D), up or down, to get desired height. Socket (F) should not show under shade (C) when the harp is adjusted correctly.
 3. Carefully tighten knobs on harp (D).