


ASSEMBLY INSTRUCTIONS

Sommerard Triple Arm Floor Lamp

Item # ARN1009



INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

1. Carefully remove all parts from the carton.
2. Remove white plastic bushing inside of center hole on pole (B) and base (C) before assembling.
3. Thread the bottom nipple of pole (A) into the top opening of pole (B).
4. Join lamp pole (B) and lamp base (C) together, letting bottom nipple of the lamp pole (B) pass through the holes on lamp base (C).
5. From the underside of base, slide the washer (D) over the threaded nipple and then thread nut (E) onto the nipple. Use the T-wrench (F) to tighten the nut.
6. Insert light bulbs maximum 60 watt into lampholders.
7. Plug lamp into wall outlet.

Adjustment Instructions:

1. Loosen adjustment keys (G) or (H).
2. Adjust lamp by swinging lamp shade or lamp arm to desired angle.
3. Tighten adjustment keys (G) or (H).

CAUTION:

If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.

DISPOSAL:

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.

***Clean with a dry, soft cloth only. Use no harsh abrasives or chemical agents.



VISUAL COMFORT & Co. Est. 1987