

SP

DRX-1's Factory Pre-Sets for Kits 1 through 8

Kit #1 Pre-Programmed Sound: Simmons Unmistakeable "Electronic" Sound

| Parameter<br>Pad | Pitch | Bend | Osc./Noise | Overtone | Attack | Filter | Decay | Level |
|------------------|-------|------|------------|----------|--------|--------|-------|-------|
| Snare Drum       | 5     | 19   | 10         | 0        | 18     | 18     | 11    | 12    |
| Bass Drum        | 11    | 19   | 19         | 0        | 12     | 17     | 14    | 14    |
| Tom Tom (L)      | 11    | 17   | 18         | 0        | 17     | 19     | 9     | 10    |
| Tom Tom (R)      | 10    | 17   | 18         | 0        | 17     | 19     | 9     | 10    |
| Floor Tom        | 7     | 17   | 18         | 0        | 17     | 19     | 9     | 11    |

Kit #2 Pre-Programmed Sound: Acoustic Drum Sound - "Heavy Metal"

| Parameter<br>Pad | Pitch | Bend | Osc./Noise | Overtone | Attack | Filter | Decay | Level |
|------------------|-------|------|------------|----------|--------|--------|-------|-------|
| Snare Drum       | 10    | 9    | 10         | 10       | 13     | 14     | 12    | 13    |
| Bass Drum        | 8     | 19   | 15         | 12       | 12     | 14     | 13    | 14    |
| Tom Tom (L)      | 9     | 15   | 13         | 9        | 12     | 12     | 8     | 10    |
| Tom Tom (R)      | 8     | 15   | 13         | 9        | 12     | 12     | 8     | 10    |
| Floor Tom        | 8     | 15   | 13         | 9        | 12     | 12     | 8     | 11    |

Kit #3 Pre-Programmed Sound: "Hand Clapping" Sound

| Parameter<br>Pad | Pitch | Bend | Osc./Noise | Overtone | Attack | Filter | Decay | Level |
|------------------|-------|------|------------|----------|--------|--------|-------|-------|
| Snare Drum       | 19    | 3    | 9          | 15       | 15     | 14     | 13    | 13    |
| Bass Drum        | 12    | 17   | 13         | 11       | 16     | 11     | 12    | 14    |
| Tom Tom (L)      | 16    | 10   | 12         | 13       | 13     | 12     | 6     | 10    |
| Tom Tom (R)      | 15    | 11   | 12         | 13       | 13     | 12     | 6     | 10    |
| Floor Tom        | 13    | 13   | 12         | 13       | 13     | 12     | 7     | 11    |

Kit #4 Pre-Programmed Sound: "Syndrum" Sound (Pre-Simmons)

| Parameter<br>Pad | Pitch | Bend | Osc./Noise | Overtone | Attack | Filter | Decay | Level |
|------------------|-------|------|------------|----------|--------|--------|-------|-------|
| Snare Drum       | 17    | 16   | 11         | 15       | 12     | 15     | 14    | 12    |
| Bass Drum        | 9     | 18   | 18         | 18       | 13     | 16     | 15    | 14    |
| Tom Tom (L)      | 11    | 19   | 15         | 15       | 14     | 13     | 9     | 10    |
| Tom Tom (R)      | 10    | 19   | 15         | 15       | 14     | 13     | 9     | 11    |
| Floor Tom        | 10    | 19   | 15         | 15       | 14     | 13     | 10    | 13    |

SP

Kit #5

Pre-Programmed Sound: Acoustic Drum Sound

| Parameter<br>Pad | Pitch | Bend | Osc./Noise | Overtone | Attack | Filter | Decay | Level |
|------------------|-------|------|------------|----------|--------|--------|-------|-------|
| Snare Drum       | 10    | 5    | 11         | 14       | 14     | 13     | 11    | 13    |
| Bass Drum        | 9     | 17   | 16         | 3        | 14     | 11     | 14    | 14    |
| Tom Tom (L)      | 11    | 14   | 14         | 4        | 13     | 11     | 10    | 11    |
| Tom Tom (R)      | 10    | 14   | 14         | 4        | 13     | 11     | 10    | 11    |
| Floor Tom        | 9     | 14   | 14         | 4        | 13     | 11     | 10    | 12    |

Kit #6

Pre-Programmed Sound: Latin Percussion Sound

| Parameter<br>Pad | Pitch | Bend | Osc./Noise | Overtone | Attack | Filter | Decay | Level |
|------------------|-------|------|------------|----------|--------|--------|-------|-------|
| Snare Drum       | 12    | 0    | 15         | 17       | 19     | 13     | 11    | 11    |
| Bass Drum        | 12    | 19   | 15         | 11       | 13     | 17     | 12    | 14    |
| Tom Tom (L)      | 19    | 0    | 15         | 17       | 19     | 13     | 6     | 10    |
| Tom Tom (R)      | 17    | 0    | 15         | 17       | 19     | 13     | 6     | 11    |
| Floor Tom        | 17    | 0    | 15         | 18       | 19     | 13     | 8     | 11    |

Kit #7

Pre-Programmed Sound: "Electronic" Rock Sound

| Parameter<br>Pad | Pitch | Bend | Osc./Noise | Overtone | Attack | Filter | Decay | Level |
|------------------|-------|------|------------|----------|--------|--------|-------|-------|
| Snare Drum       | 7     | 8    | 6          | 8        | 15     | 9      | 13    | 12    |
| Bass Drum        | 11    | 17   | 12         | 14       | 15     | 12     | 18    | 14    |
| Tom Tom (L)      | 12    | 15   | 7          | 7        | 14     | 8      | 11    | 13    |
| Tom Tom (R)      | 11    | 15   | 7          | 0        | 14     | 6      | 11    | 13    |
| Floor Tom        | 10    | 15   | 7          | 0        | 14     | 4      | 12    | 15    |

Kit #8

Current Values in Program #8

| Parameter<br>Pad | Pitch | Bend | Osc./Noise | Overtone | Attack | Filter | Decay | Level |
|------------------|-------|------|------------|----------|--------|--------|-------|-------|
| Snare Drum       | 7     | 17   | 9          | 0        | 18     | 18     | 9     | 13    |
| Bass Drum        | 15    | 19   | 19         | 0        | 16     | 19     | 14    | 16    |
| Tom Tom (L)      | 10    | 17   | 18         | 0        | 18     | 19     | 9     | 14    |
| Tom Tom (R)      | 12    | 17   | 19         | 0        | 18     | 19     | 9     | 14    |
| Floor Tom        | 8     | 19   | 15         | 0        | 19     | 19     | 9     | 14    |