


FFD27ESSSS

450 Series 36 Inch Stainless Steel
French Door Refrigerator

FORTÉ

Parts List



FFD27ESSSS Parts List

No.	Description of Spare Part	SKU	QTY
1	Water supply inlet cover for FFD27ESSSS	F90000481	1
2	Self-tapping screw ST4.2x16 for FFD27ESSSS	F90000482	36
3	Pipe for FFD27ESSSS	F90000483	1
4	Pipe for FFD27ESSSS	F90000484	1
5	Pipe cover for FFD27ESSSS	F90000485	1
6	Tap Water Joint Connector for FFD27ESSSS	F90000486	1
7	Connector Nut for FFD27ESSSS	F90000487	1
8	Self-tapping screw ST4.2x13 for FFD27ESSSS	F90000488	10
9	Main control panel part for FFD27ESSSS	F90000489	1
10	Control board box cover for FFD27ESSSS	F90000490	1
13	Self-tapping screw ST4.2x16 for FFD27ESSSS	F90000491	10
14	Power line for FFD27ESSSS	F90000492	1
15	Filter drier for FFD27ESSSS	F90000493	1
16	Compressor room back guard part for FFD27ESSSS	F90000494	1
17	Connect tube for FFD27ESSSS	F90000495	1
18	Fastening components M6x25 for FFD27ESSSS	F90000496	2
19	Impact board for FFD27ESSSS	F90000497	1
20	Right impact board for FFD27ESSSS	F90000498	1
21	Compressor parts for FFD27ESSSS	F90000499	1
147	Variable frequency board for FFD27ESSSS	F90000500	1
22	Steel sleeve for FFD27ESSSS	F90000501	2
23	Connect tube for FFD27ESSSS	F90000502	1
24	Process tube for FFD27ESSSS	F90000503	1
26	Special flange self-tapping screw ST4.8x16 for FFD27ESSSS	F90000604	12
27	Fan motor for FFD27ESSSS	F90000357	1
25	Refrigerator fan motor for FFD27ESSSS	F90000358	1
32	Compressor base part for FFD27ESSSS	F90000359	1
29	Evaporating dish for FFD27ESSSS	F90000360	1
31	Bottom condenser for FFD27ESSSS	F90000361	1
28	Compressor base part for FFD27ESSSS	F90000362	1
30	roll wheel for FFD27ESSSS	F90000363	2
33	Drain connecting pipe for FFD27ESSSS	F90000364	1
34	Electromagnetic valve assembly for FFD27ESSSS	F90000365	1
35	Installation clip for FFD27ESSSS	F90000366	1
36	Two-way connector part for FFD27ESSSS	F90000367	2
37	Installation clip for FFD27ESSSS	F90000368	5
38	Snap ring for FFD27ESSSS	F90000369	11
39	Clip for FFD27ESSSS	F90000370	2
40	Two-way connector part for FFD27ESSSS	F90000371	1

41	Self-tapping screw ST4.2x13 for FFD27ESSSS	F90000372	3
42	ice-maker inlet cover for FFD27ESSSS	F90000373	1
148	sponge block for FFD27ESSSS	F90000374	1
43	R2-room door for FFD27ESSSS	F90000375	1
44	Door stop for FFD27ESSSS	F90000376	1
45	Door stopper for FFD27ESSSS	F90000377	1
46	Self-tapping screw ST4.2x13 for FFD27ESSSS	F90000378	2
47	Magnetic core for FFD27ESSSS	F90000379	2
48	Gasket part for FFD27ESSSS	F90000380	2
50	Vibration pad for FFD27ESSSS	F90000381	4
49	Upper shelf for FFD27ESSSS	F90000382	6
52	R1-room door for FFD27ESSSS	F90000383	1
51	Vertical baffle part for FFD27ESSSS	F90000384	1
53	LED light for FFD27ESSSS	F90000385	1
54	LED light cover for FFD27ESSSS	F90000386	1
55	Door stop for FFD27ESSSS	F90000387	1
56	Door stopper for FFD27ESSSS	F90000388	1
57	Wind channel part in refrigerator chamber for FFD27ESSSS	F90000389	1
58	Temperature sensor part for FFD27ESSSS	F90000390	1
59	Electric wind gate for FFD27ESSSS	F90000391	1
136	Refrigerated wind channel foam for FFD27ESSSS	F90000392	1
137	Wind gate foam for FFD27ESSSS	F90000393	1
138	refrigerator air duct cover for FFD27ESSSS	F90000394	1
139	sponge block for FFD27ESSSS	F90000395	1
60	Wind channel part in freezer chamber for FFD27ESSSS	F90000396	1
61	Temperature sensor part for FFD27ESSSS	F90000397	1
62	Wind blade for FFD27ESSSS	F90000398	1
63	Back fan motor cover for FFD27ESSSS	F90000399	1
64	Refrigerator fan for FFD27ESSSS	F90000400	1
65	Back fan motor cover for FFD27ESSSS	F90000401	1
140	wind channel cover board in freezer chamber for FFD27ESSSS	F90000402	1
141	Wind channel board in freezer chamber for FFD27ESSSS	F90000403	1
142	Wind channel foam in freezer chamber for FFD27ESSSS	F90000404	1
143	sponge block for FFD27ESSSS	F90000405	1
144	sponge strip for FFD27ESSSS	F90000406	2
66	F-Room door for FFD27ESSSS	F90000407	1
67	Left rail bracket for FFD27ESSSS	F90000408	1
68	Gasket part for FFD27ESSSS	F90000409	1
69	Right rail bracket for FFD27ESSSS	F90000410	1
70	Shelf part for FFD27ESSSS	F90000411	1
71	Shelves assembly for FFD27ESSSS	F90000412	3

72	Crisper box cover part for FFD27ESSSS	F90000413	1
73	Crisper box part for FFD27ESSSS	F90000414	2
74	Crisper box cover part for FFD27ESSSS	F90000415	1
75	Front cover of multifunctional room for FFD27ESSSS	F90000416	1
76	Left guided rail part for drawer for FFD27ESSSS	F90000417	1
77	Multifunctional drawer part for FFD27ESSSS	F90000418	1
78	Right guided rail part for drawer for FFD27ESSSS	F90000419	1
79	Special flange self-tapping screw M5x16 for FFD27ESSSS	F90000420	18
80	Left guided rail part for drawer for FFD27ESSSS	F90000421	1
81	Upper drawer part for FFD27ESSSS	F90000422	1
82	Ice box for FFD27ESSSS	F90000423	1
83	Rail link pole for FFD27ESSSS	F90000424	1
84	Bolt for FFD27ESSSS	F90000425	1
85	Right guided rail part for drawer for FFD27ESSSS	F90000426	1
86	Fixed card of magnetic core for FFD27ESSSS	F90000427	1
87	Lower drawer part for FFD27ESSSS	F90000428	1
88	Filter holder-drawing for FFD27ESSSS	F90000429	1
90	Filter components for FFD27ESSSS	F90000430	1
91	Filter part for FFD27ESSSS	F90000431	1
95	Filter holder for FFD27ESSSS	F90000432	1
92	Water baffle for FFD27ESSSS	F90000433	1
93	Self-tapping screw ST4.2x25 for FFD27ESSSS	F90000434	3
94	Filter fixed rack for FFD27ESSSS	F90000435	1
96	Draining mouth for FFD27ESSSS	F90000436	1
97	Converter switch for FFD27ESSSS	F90000437	1
98	Control box cover part for FFD27ESSSS	F90000438	1
99	Swing connecting rod for FFD27ESSSS	F90000439	1
100	Automatic ice-maker part for FFD27ESSSS	F90000440	1
101	Temperature sensor part for FFD27ESSSS	F90000441	1
102	Motor for FFD27ESSSS	F90000442	1
103	Check ice pole for FFD27ESSSS	F90000443	1
104	Self-tapping screw ST2.9x9.5 for FFD27ESSSS	F90000444	1
105	Evaporator fin assembly for FFD27ESSSS	F90000445	1
106	Evaporator parts in freezing chamber for FFD27ESSSS	F90000446	1
107	Water drain for FFD27ESSSS	F90000447	1
108	Defrost stick for FFD27ESSSS	F90000448	1
109	Tube type electric heater for FFD27ESSSS	F90000449	1
110	Refrigerator air return cover for FFD27ESSSS	F90000450	1
111	Bracket cover for FFD27ESSSS	F90000451	2
112	Fixed board for FFD27ESSSS	F90000452	1
113	Fixed board for FFD27ESSSS	F90000453	2

114	Top cover plate part for FFD27ESSSS	F90000454	1
115	Top cover for FFD27ESSSS	F90000455	1
116	Display board connection wire for FFD27ESSSS	F90000456	1
117	Reflective baffle for FFD27ESSSS	F90000457	1
118	Button display panel-drawing for FFD27ESSSS	F90000458	1
119	Lampholders fixed block for FFD27ESSSS	F90000459	1
120	Display panel part for FFD27ESSSS	F90000460	1
121	Self-tapping screw for FFD27ESSSS	F90000461	2
122	Electric connection wire for FFD27ESSSS	F90000462	1
123	Magnetic reed switch for FFD27ESSSS	F90000463	2
124	Production bar code for FFD27ESSSS	F90000464	1
125	Ajustable bottom feet part for FFD27ESSSS	F90000465	2
146	ajustable bottom feet part for FFD27ESSSS	F90000466	2
126	Roll wheel for FFD27ESSSS	F90000467	2
127	Roll wheel axis for FFD27ESSSS	F90000468	2
128	Door switch for FFD27ESSSS	F90000469	1
129	Screw M5x18 for FFD27ESSSS	F90000470	4
130	Self-tapping screw ST4.2x16 for FFD27ESSSS	F90000471	2
131	Left middle hinge part for FFD27ESSSS	F90000472	1
132	Right middle hinge part for FFD27ESSSS	F90000473	1
133	Cover LED for FFD27ESSSS	F90000474	1
134	LED light for FFD27ESSSS	F90000475	1
135	Left upper hinge part for FFD27ESSSS	F90000476	1
145	Right upper hinge part for FFD27ESSSS	F90000477	1

