MINI NETBALL NET

Assembly

- Open the cap of the base to fill with water or sand (not supplied)
- 2. Insert the adjustable stick (75cm) into the base
- 3. Insert the 2nd stick (73.5cm) into the first stick
- 4. Insert the small (9.5cm) stick
- 5. Insert the 4th (58.5cm) stick
- 6. Insert the basket

Press the bottom button on 2nd stick to adjust the stick height

Components:

- 1. Base x 1pc
- 2. Stick with 7 adjustable holes (size: 75cm x dia. 3.5cm x 1pc)
- 3. Stick with 2 adjustable holes (size: 73.5cm x dia. 3.2cm x 1pc)
- 4. Stick (size: 9.5cm x dia. 3.7cm x 1pc)
- 5. Stick (size: 58.5cm x dia. 3.2cm)
- 6. Basket x 1pc



