



Electronic Insect Killer USER MANUAL MODEL: FT-OD18

This Awoco Electronic Insect Killer utilizes the black light (ultra-violet rays) of the wave length, which is proved to be the most effective lure for light sensitive flying insects, such as flies, moths, mosquitoes and other flying insects. These insects are electrocuted upon touching the inner high voltage grids. No chemicals, no smells, no sprays, no mess, pollution free and harmless to humans and pets. It is ideal for using in houses, offices, factories, food outlets, hospitals and other places.

Cautions and Warnings

1. Household use only! Suited for indoor and outdoor use. IPX4 waterproof.
2. High voltage! DO NOT touch the inner electric grids while the device is plugged in.
3. Never put metal objects inside the grids while in operation.
4. Keep away from flammables.
5. Check the local voltage before operating.
6. Keep the device out of reach from children.
7. This device CANNOT be used in barns, stables and similar locations.
8. This device CANNOT be used in locations where contains flammable vapor or explosive dust.
9. Unplug the device before replacing the lamp. The lamp replacement can only be performed by a qualified technician.
10. If the power cord is damaged, it must be replaced by the manufacturer, its service agent or qualified technician in order to avoid a hazard.
11. An electric shock hazard may occur if water from a garden hose is directed at the device in operation. When using an extension cord, keep the socket outlet away from moisture to avoid damage to the cord.
12. This device IS NOT intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they are supervised or given instruction concerning the usage of this device by a person responsible for their safety.

How to Use

This device can be hung from the ceiling or camping rope, or place on a flat surface.

1. Consider and choose the best location for the device.
2. Determind whether to hang the device or place it on a flat surface.
3. Plug in the power cord and start using the device.


Maintenance

1. Unplug the power cord and wait for 5 minutes.
2. Twist open (from right to left) the removable tray at the bottom of the device.
3. Empty the dead insects inside the tray and then rinse to fully clean it.
4. Put the tray back to position and twist lock it (from left to right).
5. Plug in the power cord.

Main Power

120V~60Hz

Components and Parts



Disposal

- DO NOT dispose this device as unsorted municipal waste. Separate collection of such waste for special treatment is necessary.
- This device MUST NOT be disposed together with domestic wastes. This device needs to be disposed at an authorized location for recycling of electrical and electronic appliances.



Product Warranty

- This product is warranted for a limited period of ONE YEAR Parts, begins from the date of purchase.
- This limited warranty is applied to the original retail purchaser and valid only for products purchased for home use in the continental United States of America.
- This limited warranty is non-transferable and does not extend to the subsequent owners of this product.
- Any applicable implied warranties, including the warranty of merchantability, are limited in duration to a period of express warranty as provided herein beginning with the date of original purchase at retail and, no warranties, whether express or implied, shall apply to this product thereafter.

Product Support

If you need help with other issues not listed above, please contact us at
1-888-412-3428, between 10 AM and 5 PM, Monday - Friday, Pacific Time.

Or

Email us at sales@awoco.com.

MADE IN CHINA