












# SAMSUNG


Unpacking and Installation Guide  
 Guide de déballage et d'installation  
 Guía de desembalaje e instalación  
 Manual de desempacotamento e instalação  
 Auspacken und Installationsanleitung  
 Guida al disimballaggio e all'installazione







7



8




9



	A	B	C	D	E	F	G	H
55QN9*C 55QNC9*	48.2 inches (1225.4 mm) (122.54 cm)	27.8 inches (706.6 mm) (70.66 cm)	0.8 inches (21.3 mm) (2.13 cm)	30.1 inches (768.4 mm) (76.84 cm)	9.1 inches (232.1 mm) (23.21 cm)	54.6 inches (138 cm)	39.2 lbs (17.8 kg)	45.4 lbs (20.6 kg)
65QN9*C 65QNC9*	56.9 inches (1444.3 mm) (144.43 cm)	32.6 inches (829.3 mm) (82.93 cm)	0.8 inches (21.3 mm) (2.13 cm)	35.1 inches (890.4 mm) (89.04 cm)	10.7 inches (270.9 mm) (27.09 cm)	64.5 inches (163 cm)	52.5 lbs (23.8 kg)	61.5 lbs (27.9 kg)

\*: 0-9, A-Z



	VESA A x B (mm)	C (mm)	D x 4
55QN9*C 55QNC9*	300 x 200	5-6	M8
65QN9*C 65QNC9*	400 x 300		

\*: 0-9, A-Z