



**VILLANDRY**  
INSTRUCTION MANUAL



## Rivoli

---

Thank you for purchasing this VILLANDRY watch. The following instructions are provided to help familiarize yourself with the proper operation and care of your watch.

To ensure correct use, please read and follow the instructions carefully.

Movement: 9122



## TIME SETTING

1. Pull the crown out to position 2.
2. Turn the crown clockwise to set hour and minute hands to set the time.  
Take a.m./p.m. into consideration when setting the hour and minute hands to the desired time.
3. Push the crown back to position 0.

## DATE SETTING

1. Pull the crown out to position 1.
2. Turn the crown to clockwise to set the date.
3. After the date has been set, push the crown back to position 0.  
\* Do not set the date between 9:00 p.m. and 4:00 a.m. as this will cause a malfunction.

## DAY SETTING

1. Pull the crown out to position 1.
2. Turn the crown to counter-clockwise to set the day.
3. After the day has been set, push the crown back to position 0.

## ADJUST MONTH

1. Push the button "A" and adjust the month.  
\* If the button is not pushed to the end, the month is not changed perfectly.

## WINDING THE MAINSPRING

Automatic winding watches can be manually wound by turning the crown in position 0.  
Gently wind clockwise 15-20 times until the second hand starts to move naturally.

## PRECAUTIONS AND PREVENTIVE MEASURES

### Temperature

Do not expose your watch to sudden temperature changes (exposure to sunlight followed by immersion in cold water) or extreme temperatures [over 60°C (140°F) or below 0°C (32°F)].

### Magnetic Fields

Do not expose your watch to intense magnetic fields such as loudspeakers, portable telephones, computers, refrigerators, and other electromagnetic appliances.

### Shocks

Avoid thermal or other shocks as it may harm your watch. In the event of a violent shock please contact VILLANDRY.

### Care and Checks

Clean the case and bracelet regularly using a soft cloth to prevent any corrosion caused by perspiration. To clean all water-resistant watches use a toothbrush and soapy water, and then dried with soft cloth.

## Water Resistance

This watch is rated to 10ATM / 100M / 330 FT.

Water resistance of watches is rated based on laboratory pressure tests comparable to a swimmer or diver sitting still at that pressure level. However, many water-based activities involve a lot of movement and other environmental changes. These exceptions to how the watch was rated may challenge or defeat the water protection features of a water-resistant watch. The water resistance of a watch cannot permanently be guaranteed. It may be affected by the aging of gaskets or by accidental shock to the crown.

Never activate the time-setting crown and the pushers while the watch is underwater and make sure that the crown has been pushed/screwed down tightly after every operation. Do not under any circumstances open the watch yourself.

We do not recommend subjecting our watches to hot tub or jacuzzi use.

## International Warranty

VILLANDRY guarantees this watch for a period of TWENTY FOUR (24) MONTHS from the original date of purchase, with the exception of loss, theft, and damages resulting from ill treatment.

Any modification to your watch by the addition of non-original parts, or the substitution of parts with non-original parts will void your warranty.