


HAVANA LAMP

Type: Whisky
P30 Shallow Ceiling Plate



KANSA LIGHTING



FITTING INSTRUCTIONS WITH P30 – NO CROSSBAR

- ❖ 1. This fitting should only be connected by a competent person, if in any doubt please employ an electrician.
- ❖ 2. Switch off the electricity at the mains.
- ❖ 3. Remove the existing ceiling rose from the ceiling.
- ❖ 4. Thread the cable through the ceiling rose then make the appropriate terminal connections using a connecting block (not supplied). Ensure both earth wires have been connected through the same pathway. If there aren't two earth wires, your electrician is expected to install it.
- ❖ 5. When all the connections have been completed, lift the rose to the plate on the ceiling and secure it with the side screws.
- ❖ 6. Ensure that the correct type of bulb is used and that the maximum wattage has not been exceeded. See the label on the lamp itself for details.
- ❖ 7. Fix the ceiling plate securely to the ceiling using screws, the screws used in the previous rose may be suitable. Plugs will need to be used if fixing to concrete or masonry.
NB. We do not supply screws as the type and length of screw required is dependent upon your type of ceiling or connector blocks.
- ❖ 8. To clean, use a dry, soft cloth, a glass cleaner may need to be used for more stubborn marks on the glass. Do not use abrasive cleaning agents on the metalwork.