



O O O

LAMP

ON/OFF

Tap the rectangular touchpad located on the base of the lamp to turn on and off.

DIMMING/BRIGHTENING

Rest your finger on the touchpad to change the brightness of the lamp.

REVERSE DIMMING DIRECTION

While adjusting the brightness, lift your finger from the touchpad and pause half a second before touching it again to reverse the dimming direction.

