


































Flex SilBlade® LASTS YEARS NOT MONTHS!

INSTALLATION INSTRUCTIONS / INSTRUCCIONES PARA LA INSTALACIÓN / INSTRUCTIONS D'INSTALLATION

HOOK ARM HK 	SIDE LOCK PIN SL-1 	SIDE LOCK PIN SL-2 	TOP BUTTON TB 	PINCH TAB 1 PT-1 	PINCH TAB 2 PT-2 
<p>Correct Adapter Pre-Installed Correcto Adaptador Preinstalado Correct adaptateur préinstallé</p> <p>1  Adapter A</p> <p>2 </p> <p>3  "CLICK" "CLIC" "ENCLIQUER"</p>	<p>Remove Pre-Installed Adapter Retire el Adaptador Preinstalado Retirez l'adaptateur préinstallé</p> <p>1  Adapter B</p> <p>2  Adapter B</p> <p>3 </p> <p>4 </p> <p>5  "CLICK" "CLIC" "ENCLIQUER"</p>	<p>Remove Pre-Installed Adapter Retire el Adaptador Preinstalado Retirez l'adaptateur préinstallé</p> <p>1 </p> <p>2 </p> <p>3 </p> <p>4 </p> <p>5  "FINISH" "FINALIZAR" "TERMINEZ"</p>	<p>Remove Pre-Installed Adapter Retire el Adaptador Preinstalado Retirez l'adaptateur préinstallé</p> <p>1 </p> <p>2 </p> <p>3 </p> <p>4  "CLICK" "CLIC" "ENCLIQUER"</p>	<p>Remove Pre-Installed Adapter Retire el Adaptador Preinstalado Retirez l'adaptateur préinstallé</p> <p>1 </p> <p>2 </p> <p>3 </p> <p>4 </p> <p>5  "CLICK" "CLIC" "ENCLIQUER"</p>	<p>Remove Pre-Installed Adapter Retire el Adaptador Preinstalado Retirez l'adaptateur préinstallé</p> <p>1 </p> <p>2 </p> <p>3 </p> <p>4 </p> <p>5  "CLICK" "CLIC" "ENCLIQUER"</p>