


# **Custom Flex Security Wall Mount**

PAD-CFWMS


**INSTRUCTION - MANUAL** 

#### **CONTENTS:**




### **INSTRUCTIONS:**







## 2. Inserting Tablet Into Holder



2a. Insert key (G) into lock at back of holder (C). Turn counterclockwise to unlock, pull back the lock component, then slide the arms out.



2b. Insert tablet against fixed end, then slide down to hold tight. Turn key (G) clockwise to lock.



Twist the screw knob of the arms counter-clockwise to release the connection. Adjust the arms to your favorite position and then tighten the screw knob clockwise.

#### **Adjusting Tablet Holder**



Tablet holder rotates custom viewing angles. DO NOT attempt to adjust, tilt, or rotate any ball socket joints while it is fully tightened. Such actions will result in possible damage integrity of product.

