






# Hyperflex Security Kiosk Stand for Tablets (WHITE)

## INSTRUCTION MANUAL

### PAD-HSKSW


\*\*Note - Hinges may get looser and droop over time. Please tighten screws for optimum usage and efficiency.





①

Turn clockwise to  
prevent rotation



②

Bolt to countertop or  
wall with screws

