



Paragon: Premium Security Swan Neck Stand

INSTRUCTION MANUAL

PAD-PARASW

1

← Top Swan Neck Segment

← Middle Segment

← Bottom Segment

STEP 1:
Determine assembly type if it should be a stand, desktop, or kiosk setup.

Stand Assembly combination includes top swan neck, middle and bottom segment.

Desktop combination includes only top swan neck segment and bottom segment.

Kiosk combination is only top swan neck

2

STEP 2:
When assembly type is determined, screw in base plate with provided tool and bolts from below with lowest segment piece.

4pcs

3

STEP 3:
Pending which assembly has been selected, remove and tighten selected segments OR just tighten segments for more rigidity if assembly desired is already in place.

****Diagram to the left illustrates tightening of bottom and middle segments if kiosk or stand assembly was the desired setup.**

4

Opening near top in swan neck segment

Opening at bottom near base

STEP 4: (Optional)
Assembly core has a product design for cable management. Insert cables/power cords through opening at the bottom and extend through the body all the way to the opening at the swan neck segment to attach cord to tablet.

5

(Tablet Holder being locked and as illustrated from behind)

STEP 5:
Extend the holder arms to fit 7-14" tablets within and slide them to the corners for a snug fit.

Take the security cord and loop it around the body of the pole.

Afterwards, insert opposite end of the security cord into the back opening of the tablet holder as shown on the left and insert key at the same time. Rotate and lock the tablet in place. Remove key and store somewhere until needed to unlock the tablet holder.