



Using the Wall Mount Bases


Caution: Please ensure that tablet is securely fixed in




Squeeze buttons on inner circle, then remove tablet bracket from base.




Mount base to wall with included




Place tablet against one end of




Pull the opposite bracket out, then release to secure tablet.



Squeeze headpiece buttons then attach tablet bracket. Release buttons to connect.



Rotate for portrait & landscape displays



Tilt for optimal viewing angle




Attach or remove tablet fitting accessories on both sides for optimum tablet fitting


Using the Tabletop Stand




Place tablet against one end of bracket.




Pull the opposite bracket out, then release to secure tablet.



Push screw through underside. Attach circle insert and neck. Use screwdriver to tighten.




Squeeze headpiece buttons then attach tablet bracket. Release buttons to connect



Rotate for portrait & landscape displays



Use tilting headpiece for angle adjustment



Stand base rotates 360 degreees



Attach or remove tablet fitting accessories on both sides for optimum tablet fitting

