


## PAD-RSC11 User Manual


## SUPPORT@CTADIGITAL.COM

## Designed for 11-inch iPad Pro









- 1. Insert key and turn to unlock position.
- 2. Attach looped end to permanent fixture and pass cable head through loop.
- 3. Attach cable head to K-slot on tablet case.
- 4. Turn key to lock, then remove key.

