



PAD-SCKT10


# Security Case with Kickstand & Anti-Theft Cable

for iPad 10.2" 7th-9th Gen, iPad Air 3, Pad Pro 10.5"


## INSTRUCTION MANUAL

Thank you for choosing CTA Digital's product. We hope that you will enjoy using it. Please follow the guidelines and instructions as laid out in this instruction manual


### PACKAGE CONTENTS:




x1



x1




x1



x2


## INSTRUCTIONS:

### 1. Inserting Tablet into Case.




- Remove the silicon cover of the plastic case.
- Pull the stopper of the plastic case.
- Slide the tablet into the case from bottom side.
- Push the stopper back to fix the tablet.
- Install the plastic base into silicon cover.

### 3. Tablet Locking.




- Use key push and turn it to unlock position.
- Tie the cable to fixed object.
- Insert the tip of lock into the case lock slot.
- Turn the key to let the lock at lock position.

### 2. Removing Tablet from Case.



- Remove the silicon cover.
- Release the stopper.
- Take the tablet out from upper side.
- Push the stopper back.
- Install the plastic base into silicon cover.

### 4. Tablet Unlocking.



- Use the key to move lock to unlock position.
- Release the lock.