




# Security Translucent Acrylic Stand

## INSTRUCTION MANUAL

### PAD-STAK



4 Fitting corners are pre-installed. If position not accurate when install tablet, first loose the corner screws a little and adjust the corner position to fit the tablet. Tighten again after adjustment.

