CTA Digital - Innovative Accessories

Product Name: Anti-Theft Security Kiosk Stand Pro for iPad Pro & Tablets 9.7"–12.9"

Product Model: PAD-UATP

Thank you for choosing CTA Digital's product. We hope that you will enjoy using it.
Please follow the guidelines and instructions as laid out in this instruction manual.

Package Contents (After assembly)

- Fixed holder grip
- Tablet holder
- Holder Connector
- Lock catch
- Keys
- Adjustable holder Grip
- Base connector
- Tube
- Base

1 Insert the holder connector into the tube

2 Tighten the screws on both sides after inserting the holder connector

3 Tighten the 4 pcs screw after inserting the base connector.

To use the stand:

1

Holder

Place the stand on a flat surface, such as a desk or table. Then adjust the holder to the horizontal position as shown.

2

Tablet — Movable holder grip — Push

Put the tablet corner into the fixed holder grip and move the adjustable holder grip to secure the tablet by the diagonal corners.

Lock catch
Catch
Push
Release
Turn — Lock / Unlock

Push the lock catch on the back of the holder to stop the adjustable holder grip after the tablet is secured by the holder and then turn the key to lock it.

3

To prevent the tablet from dropping, please make sure the tablet has been clamped securely before adjusting the holder angle you need.

Cable protector

Protects cable threaded through the metal stand

Hook the protectors over the cable

The cable goes through the tube with protectors

Allign the protector so the incision is horizontal

Set the protectors on the U-shaped opening