



**DIMMING / TUNEABLE WHITE / RGBW RF CONTROLLERS**



BL-PC-TOUCH-1DIM



BL-PC-TOUCH-1CCT



BL-PC-TOUCH-1RGBW

CODE	COLOUR CONTROL	FUNCTION
BL-PC-TOUCH-1DIM	Single Colour dimming	On/off, dimming adjustment wheel
BL-PC-TOUCH-1CCT	Tuneable White	On/off, temperature wheel, brightness
BL-PC-TOUCH-1RGBW	RGB / RGBW	On/off, colour wheel, brightness

OUTPUT VOLTS	CR2450 Battery
BATTERY LIFE	Approx. 2 years
DIMENSIONS	W40 × L40 × H10mm
HOUSING	PVC casing
WARRANTY	5 years
COMPLIANCE	
INGRESS PROTECTION	Indoor use only
CONTROL	RF
FREQUENCY	433.92 MHz
MAX. DISTANCE FROM RECEIVER	Up to 40m inside building

**FUNCTION**

- Remote control rolling code 433.92 MHz
- Central touch push button and touch wheel
- Ideal for dimming actions

**TRANSMITTER PROGRAMMING**

This procedure is used to programme a channel in order to then associate it with a compatible receiver. Access to the receiver is required to carry out the following procedure.

**Procedure:**

1. Activate the receiver on which you want to use the transmitter in “multifunctional remote control radio programming” mode and select the function that you want to associate with the key (see receiver manual)
2. Press the desired key, the receiver’s LED flashes three times to signal it has been received.
3. The transmitter goes back into stand-by.

**CONTROL**



**SHORT PRESS**

1DIM = ON  
1CCT / 1RGBW = ON/OFF



**LONG PRESS**

1DIM = OFF  
1CCT / 1RGBW = Brightness up / down



**ROTATION**

1DIM = Brightness up / down  
1CCT = Colour temperature up / down  
1RGBW = Colour selection

**INSTALLING BATTERY**

