

## ACCESSORIES

Connectors & end caps require sealing internally with silicone for IP66 protection.

### LITE

ACCESSORY	CODE
END FEED CONNECTOR IP66	BL-LS-4301
BOTTOM FEED CONNECTOR IP66	BL-LS-4302
END CAP IP66	BL-LS-4305
MOUNTING CLIP 20MM	BL-LS-4315
POWER FEED CABLE (1000MM)	BL-LS-4310




END FEED CONNECTOR



BOTTOM FEED CONNECTOR



END CAP



MOUNTING CLIP 20MM

### CURVE

ACCESSORY	CODE
SIDE FEED CONNECTOR IP66	BL-LS-4360
BOTTOM FEED CONNECTOR IP66	BL-LS-4361
END CAP IP66	BL-LS-4362
MOUNTING CLIP 30MM	BL-LS-4359
POWER FEED CABLE (1000MM)	BL-LS-4358




SIDE FEED CONNECTOR



BOTTOM FEED CONNECTOR



END CAP



MOUNTING CLIP 30MM

### SHEER


ACCESSORY	CODE
SIDE / BOTTOM FEED CONNECTOR IP66	BL-LS-4331
END CAP IP66	BL-LS-4332
MOUNTING CLIP 30MM	BL-LS-4330
POWER FEED CABLE (1000MM)	BL-LS-4310



SIDE / BOTTOM FEED CONNECTOR



END CAP



MOUNTING CLIP 30MM

### DUO

ACCESSORY	CODE
END FEED CONNECTOR IP66	BL-LS-4380
END CAP IP66	BL-LS-4381
ALUMINIUM MOUNTING PROFILE 1000MM	BL-LS-4382
CURVE PROFILE 1000MM (COMES IN 2 x 500MM PIECES)	BL-LS-4383
POWER FEED CABLE (1000MM)	BL-LS-4310



END FEED CONNECTOR



END CAP



ALUMINIUM MOUNTING PROFILE 1000MM



CURVE PROFILE 1000MM