

EN BOLT
User Manual
TWS Bluetooth Speaker

BOSS Audio Systems
3451 Lunar Court Oxnard, CA 93030
www.bosssaudio.com
805-751-4853 Customer Service
Tech Support: www.bosssaudio.com/support

0923

1 Thank you for choosing our product!
Please read the instructions carefully so that you will know how to operate this product properly.
After you have finished reading the instructions, keep the document in a safe place for future reference.

This Package Contains

2x Portable Bluetooth Speakers
2x Micro USB Cables
2x 3.5mm AUX Cables
2x Carabiner Clips
User Manual + Warranty Card

2 Important

Safety Instructions

- Do not disassemble the product.
- Handle the product carefully. Jolts, impacts or a fall even from a low height may damage the product.
- Use original or certified cables only.
- Do not place the product near bare flames or other heat sources.
- Protect the product from extreme temperatures, and direct sunlight.
- The product contains built-in batteries that are non-replaceable. Never attempt to remove the batteries yourself.
- Do not expose the product to excessive heat. Do not expose the product to temperature above 60°C, or dispose of in fire or water.
- Servicing must only be carried out by a technician. Contact our technical support for any service questions.
- Clean the product with a dry, fibre-free cloth. Do not use any corrosive cleaning agent.
- The product is resistant against splashing water. Do not submerge.

Care of the Environment

Do not throw away the product with normal household waste at the end of its life. Follow your local laws if/when disposing of electronic products. Only remove the built-in batteries when you intend to dispose of the product. Have the batteries removed by trained professionals, and dispose of the batteries correctly.

3 Getting to Know Your Product

- 1 + / -
- 2 M
- 3 Built-in Emergency Flashlight
- 4
- 5 Carabiner Clip Hook
- 6 Bluetooth/Charging LED Indicator
- 7 3.5mm AUX Input (from a MP3 player or mobile phone)
- 8 Micro SD Card Slot (for music playback)
- 9 Micro USB Charging Port
- 10 Rubber Connector Cover
- 11 USB-A Port (for music playback)

4 Getting Started

Charge

Charge your speaker when you hear a voice prompt of low battery, or the speaker cannot power on.

- Using the supplied Micro USB cable, connect the charging port on the speaker to the USB port on your computer or a power adapter (not included).

When charging, the LED indicator on the speaker turns red. When fully charged, the red indicator turns off.

Power On/Off

Long press M to power on or off. When powered on, the LED indicator turns blue.

To save power, the speaker powers off automatically after nine minutes of inactivity (unless 3.5mm audio cable is inserted).

Adjust Volume

Long press + / - to increase or decrease volume.

5 Bluetooth

TWS Usage

The product comes in pair to let you enjoy true wireless stereo (TWS) sound via Bluetooth streaming.

Perform pairing before you use TWS function for the first time.

Step 1: Pair two speakers with each other (TWS connection)

- Power on both speakers. The LEDs on both speakers flash blue, indicating two speaker are in pairing mode.
- Press twice on either speaker to set up True Wireless connection. The two speakers will pair with each other after five to ten seconds. Once paired, both speakers will automatically connect when powered on.

Step 2: Pair to a mobile phone

- On your mobile phone, enable Bluetooth and select "BOSS AUDIO SYSTEMS BOLT". Then the main speaker will pair with your mobile phone, indicated by a voice prompt. The LED indicator on the main speaker will also turn solid blue.

Step 3: Play music from your mobile phone

- Music from the mobile phone will play on both speakers in True Wireless Stereo. One speaker is left channel, the other speaker is right channel.

TIP: The speaker automatically connects to the previously paired device when powered on. If no paired device is found, the LED on the speaker will flash slowly for nine minutes before powering off automatically.

Connect with a different device in TWS mode

Press M twice on the main speaker to disconnect the currently connected device, then pair a different mobile phone with the speaker.

6 Bluetooth

Switch between standalone and TWS mode

In TWS mode, press twice on either speaker. The two speakers will disconnect with each other to become standalone. To switch back to TWS mode, press twice on the main speaker (with solid blue LED).

Playback Control

- To pause or resume playback, short press .
- To select the next or previous track, short press + / - .
- To increase or decrease volume, long press + / - .

Hands-free Phone Calls

When a phone call is received, music playback will pause.

- To answer a call, short press .
- To reject a call, long press .
- To end a call, short press .

NOTE: If the speaker fails to function normally, reset the speaker. Use a non-metal pin to press the button inside the 3.5mm AUX input, and then the speaker will be reset.

7 USB/ Micro SD Card Playback

When switching to USB, Micro SD card or AUX mode, the two speakers will disconnect with each other to work independently.

When switching back to Bluetooth mode, the two speakers will automatically re-connect with each other to work as TWS.

- Insert a USB flash drive or Micro SD card to the USB-A port or Micro SD card slot on the speaker.
- Short press M to select USB mode or SD card mode. Mode selection will be indicated by a voice prompt.
- To pause or resume playback, short press .
- To select the next or previous track, short press + / - .
- To increase or decrease volume, long press + / - .

8 AUX/ Emergency Flashlight

AUX Input

- Connect the 3.5mm AUX input on the speaker to the headphone jack on your mobile phone (or MP3 player), using the following cable.
 - For a mobile phone with 3.5mm headphone jack, use the supplied 3.5mm audio cable.
 - For a mobile phone with a USB-C port, use a USB-C to 3.5mm plug adapter (not included).
 - For an iPhone, use a lightning to 3.5mm plug adapter (not included).
- Short press M to select AUX Input mode, indicated by a voice prompt.
- Start playback on the connected device and audio will play on the connected speaker.
 - To pause or resume playback, short press .
 - To increase or decrease volume, long press + / - .

Emergency Flashlight

Power on the speaker. Long press on the speaker to turn on or off the flashlight.

Attention. Do not look directly into the beam!

9 Specifications

Power input.....5 VDC, 1A
Micro USB charging port

Battery3.7V, 1200mAh
Lithium-ion, built in, rechargeable

Speaker drivers (Ø)2 x 45mm (each speaker)

Signal-to-noise ratio.....>70dB

THD+D<10%

Playtime.....Up to 12 hours

USB/Micro SD cardUp to 32GB

Wireless.....Bluetooth 5.0 + EDR

Bluetooth profiles.....HFP, A2DP, AVRCP

Ingress protection ratingIPX4

Dimensions (Ø x W x H)2.72" x 3.11" x 8.35" (69 x 79 x 212 mm)

Weight0.93 lbs/ 0.42 kg (each speaker)

Specifications are subject to change without notice.

Bluetooth

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by BOSS Audio Systems are under license. Other trademarks and trade names are those of their respective owners.