QUICK SET UP GUIDE SALEM VHRP-1300 5-in-1 Turntable System

BASIC SETUP OF THE VHRP-1300:

- 1. Connect the power adaptor to an AC outlet.
- Turn on the unit by turning the POWER/VOL knob and the power LED indicator lights up. Your system is now ready to play your music. Please refer to the Operations section of this manual for details.

PREPARE TURNTABLE FOR PLAYING RECORDS

- 1. Remove cap protecting stylus.
- 2. Remove twist tie used to secure the Tone Arm in place.

CONNECT BLUETOOTH® IN

- 1. Turn the Function switch to the Bluetooth® In mode. You will hear a voice notification and the blue LED will begin flashing.
- On your external device search for the Bluetooth® device named "VICTOR VHRP-1300" and select it. You will hear another voice notification indicating you have connected successfully.

CONNECT BLUETOOTH® OUT

- 1. Turn the Function switch to the Bluetooth $\ensuremath{\mathbb{B}}$ out mode.
- 2. Put your external device (speakers, headphones, etc.) into pairing mode. The LED light flashes slowly while the connection is searching. The LED light stays on after the connection is successful. Then you can transmit turntable/AUX audio signal.

*This product has been manufactured and sold under the responsibility of NAXA ELECTRONICS INC. VICTOR and the DOG & GRAMOPHON
logo are trademarks used under license by NAXA ELECTRONICS INC. Further information at <u>www.victor-brand.com</u> . All other products,
services, companies, trademarks, trade or product names and logos referenced herein are the property of their respective owners.







